




Purchase Date: ___ / ___ / ___ Order/Customer Reference Number: _____

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products can be requested with the 1-year warranty period. Proof of purchase must be provided. This includes the date of the purchase as well as photos of the product defect. Photos are used to determine the cause of the defect and to provide future quality control. The request will be reviewed, and replacement pieces will be sent at our discretion. For warranty information, visit <https://tiny.cc/SunnydazeWarranty>

If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at <https://tiny.cc/SunnydazeContact>



RESIN WICKER OUTDOOR TRASH CANS NHU-8641

Read all information carefully before using this product. Save this document for future reference.

CARE & MAINTENANCE

SAFE USE: For residential use only. Only use on a flat, level surface.

CLEANING: Brush, vacuum or use a garden hose to remove loose dirt and debris. If using a spray nozzle, use gentle or medium pressure settings; high-pressure spray settings may damage the construction of the unit and void the product warranty.

Mix 1/4 cup of soap or a mild detergent with 1 gallon of warm water. Use a soft-bristle brush to gently scrub away dirt and grime.

Thoroughly rinse, ensuring all soap residue has been removed. To prevent water spots, dry with a soft, lint-free cloth. Then, allow it to air dry.

EXPOSURE: Over time, sunlight and weather elements may degrade and change the color of this product. Damage caused by exposure to weather elements is not cause for return and is not covered under the manufacturer warranty.

STORAGE: Store in a dry, indoor location. Cover to prevent dust build-up.

! SAFETY STATEMENTS & WARNINGS !

- Do not lean or put full body weight onto the sides if reaching inside the unit.
- Do not use in the proximity of open flame or flammable/combustible chemicals.
- Keep unit a safe distance from heat sources such as fire pits, patio heaters, and grills.
- Do not allow children to use this product.
- Do not use harsh chemicals or abrasive materials to clean this unit.
- This product is for residential use only; institutional or commercial use will void this warranty.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with the product or it was damaged during shipping, please contact our customer service team through one of the methods mentioned at the top of page 1. Please have the item number and order information ready to expedite response time.

! WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

