

THUNDERBOLT 44" SNOW RIDER OWNER'S MANUAL



THANK YOU!

Thank you for purchasing this product.

We work around the clock and around the globe to ensure that our products maintain the highest possible quality. However, in the rare instance that your product is defective or missing parts, contact your retailer, or call 800-759-0977, to submit parts requests or warranty claims. Please read the warranty information at the back of this owner's manual for further details.

**IMPORTANT! PLEASE READ THIS OWNER'S MANUAL
IN ENTIRETY BEFORE USING YOUR PRODUCT.**

OPERATING INSTRUCTIONS

Use of this product involves inherent risks of injury or death. To increase your enjoyment and to reduce your risks use common sense and strictly follow these rules:

- Not for children under 3 years. Adult supervision required.
- Familiarize yourself with all applicable local laws, the proper use of the equipment and inherent risks.
- Do not sled with more than 2 people on this product adhering to the maximum load weight listed below.
- Do not use at speeds that exceed the skills of the rider.
- Do not operate sled under the influence of alcohol or drugs.
- Keep legs and arms on sled at all times. Never place wrists or feet through handles or towing harness.

THE WARNINGS AND PRACTICE SET FORTH ABOVE REPRESENT SOME COMMON RISKS ENCOUNTERED BY USERS. PLEASE USE COMMON SENSE AND GOOD JUDGEMENT.

PROPER INFLATION:

- 1) Choose flat ground making sure there are no stones, gravel, glass, or any other sharp objects.
 - 2) It is recommended that you use only a hand or foot pump for inflation.
- Caution:** Do not use a high-pressure air pump to inflate! Do not inflate above 1.4psi!
- 4) Unscrew the cap and insert the pump fitting into the valve. Inflate the chambers until tube is firm.

STORAGE AND MAINTAIN:

Clean the product with clear water, then leave it in shady and cool place for airing, fold it into original package and place it indoors for storage.

Caution: Do not use an alkali or acid detergent to clean product! Do not leave product exposed to direct sunlight for an extended period of time because it will shorten the useful life of product.

REPAIR INSTRUCTIONS:

Small pinholes and small puncture leaks can be repaired with the repair kit.

- a) Locate the leak.
- b) Deflate the product.
- c) Clean the area surrounding the leakage and dry thoroughly.
- d) Take out a repair patch and cut to required shape and size, which should be a little larger than the puncture area. Use glue to attach the patch over leak and press firmly (following glue instruction).
- e) You can use the product again after 24 hours of drying time.

We do not recommend repairing a leak bigger than 2 in. (5cm) for safety reasons.

Maximum Load Weight: 165 lbs.

90-DAY LIMITED WARRANTY

This product is warranted to the original purchaser to be free from defects in material or workmanship for a period of 90 days from the date of the original retail purchase.

This warranty does not cover defects or damage due to improper installation, alteration, accident or any other event beyond the control of the manufacturer. Defects or damage resulting from misuse, abuse or negligence will void this warranty. This warranty does not cover scratching or damage that may result from normal usage.

This product is not intended for institutional or commercial use; the manufacturer does not assume any liability for such use. Institutional or commercial use will void this warranty.

This warranty is nontransferable and is expressly limited to the repair or replacement of the defective product. During the warranty period, the manufacturer shall repair or replace defective parts at no cost to the purchaser. Shipping charges and insurance are not covered and are the responsibility of the purchaser. Labor charges and related expenses for removal, installation or replacement of the product or components are not covered under this warranty.

The manufacturer reserves the right to make substitutions to warranty claims if parts are unavailable or obsolete.

The manufacturer shall not be liable for loss of use of the product or other consequential or incidental costs, expenses or damages incurred by the consumer of any other use. The user assumes all risk of injury resulting from the use of this product.

This warranty is expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use to the extent permitted by Federal or state law. Neither the manufacturer nor any of its representatives assumes any other liability in connection with this product.

All warranty claims must be made through the retailer where the product was originally purchased. A purchase receipt or other proof of date of purchase will be required to process all warranty claims. The model number and part numbers found within the assembly instructions will be required when submitting any parts requests or warranty claims.

For further warranty information or inquiries, please call 800-759-0977