

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at [www.serenityhealth.com/warranty/](http://www.serenityhealth.com/warranty/)

If you have any questions, comments or concerns, feel free to contact us by phone at 888-881-4668, by email: [customerservice@serenityhealth.com](mailto:customerservice@serenityhealth.com), or via our contact us page at [www.SerenityHealth.com/contact-us/](http://www.SerenityHealth.com/contact-us/)

# TURTLE TRIO OUTDOOR WATER FOUNTAIN LZH-178



Read the assembly instructions carefully and follow the care instructions.  
Keep these instructions for future reference.

Select a smooth, level surface to place the fountain. Assemble components of this fountain on a soft, clean surface to avoid scratching or damaging the finish.



Inspect packaging to ensure all parts are accounted for before disposing of packaging.

PARTS	QTY.
Turtle Trio Topper	1
Basin Bowl	1
Pedestal	1
Electric Submersible Pump	1

## ASSEMBLY

### STEP 1:

Align the tabs on the bottom of the basin bowl with the notches in the top of the pedestal. Place the basin bowl onto the pedestal, twist to lock them together.




### STEP 2:

Run the pump power cable through the basin bowl and pedestal, leaving enough slack to allow the pump to touch the bottom of the basin bowl.

Pull the cord out through the groove on the back-side of the pedestal.





### **STEP 3:**

Firmly connect the pump to the tube that is built into the topper. A snug fit is to be expected.

Place the pump beside the tube that is built into the basin bowl. Make sure that the pump is not 'floating' or resting on top of the tube.



### **STEP 4:**

Align the notches in the bottom of the topper with the tabs on the top of the basin bowl. Place the topper onto the bowl and twist to lock the topper onto the bowl. Pay careful attention to the pump; make sure it stays on the bottom of the basin bowl and does not detach from the water tube.

Fill the fountain with enough water to keep the pump fully submerged during operation.

Plug the power cord into an electrical outlet.

**Note:** When first used, there may be air trapped in the pump. It may take several minutes for trapped air to escape, allowing water to flow.

## **⚠ IMPORTANT INFORMATION ⚠**

### **USE & CARE**

- For outdoor use only. Some splashing is normal; adjust the flow rate on the pump if the water rate is too high.
- Check the water level frequently to ensure the pump remains fully submerged; never allow the pump to run dry as it will burn out the motor.
- Only use water in this fountain. Distilled water will help prevent mineral buildup but is not required, tap water may be used but avoid heavily chlorinated water as it may damage the fountain or pump.
- Periodically change the water to keep the water, fountain and pump clean. Remove scale and buildup regularly.  
DO NOT use harmful additives such as bleach, chlorine, etc.  
DO NOT use abrasive materials to scrub the fountain  
DO NOT use a pressure washer
- Always shut off the power supply before cleaning and maintaining the fountain and the recirculating pump.
- Take care when handling the pump; only pick it up by the body of the pump, never the power cord.
- During freezing weather, drain the fountain, disconnect the pump and store indoors; allowing ice to form may crack the fountain.

### **TROUBLESHOOTING**

- Ensure that the pump is fully submerged and add water to the basin if necessary.
- Check to make sure the power outlet is working; if in doubt about electrical connections, consult a certified electrician.
- Check the pump and tubing for obstructions.
- Check the flow control on the body of the pump as it may need to be adjusted to achieve the desired flow rate.
- If water is not flowing within several moments of the fountain being plugged in, unplug the power supply for a few moments and plug it back in; the pump may have trapped air which can prevent water from circulating properly.

**Any modification or failure to follow the recommended care will void the product warranty.**