

40 MM CARTRIDGE

Installation Instructions:

1. Turn off water supply and open handle.
2. Remove handle, dome cap, and unscrew retainer nut.
3. Remove cartridge by grasping stem with pliers and pulling straight up.
4. Replace with new cartridge.

NOTE: To adjust temperature, remove limit stop from cartridge. Turn water on. Set to desired maximum temperature. Clockwise rotation of stop increases temperature and counterclockwise rotation of stop lowers temperature. Re-install limit stop so that the lug on cartridge touches the lug on stop.

5. Re-install handle assembly.

CARTUCHO DE 40 MM

Instrucciones de Instalación:

1. Cierre la línea de agua y gire la palanca a la posición abierta.
2. Extraiga la palanca, casquete, y desatornille la tuerca de retención.
3. Extraiga el cartucho. Para hacer esto, sujete la varilla con unas pinzas y tire de ésta directamente hacia arriba.

NOTA: para ajustar la temperatura, retire el tope limite del cartucho. Abra el agua. Ajuste a la temperatura máxima deseada. Para aumentar la temperatura, gire el tope a la derecha y para disminuir la temperatura, gire el tope a la izquierda. Reinstalar el tope limite de modo que la lengüeta entre en contacto con la lengüeta del cartucho.

5. Vuelva a armar el ensamble del mando.

