



Purchase Date: ___/___/___ Order/Customer Reference #: _____

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products can be requested within the 1-year warranty period. Proof of purchase must be provided. This includes the date of the purchase as well as photos of the product defect. Photos are used to determine the cause of the defect and to provide future quality control. The request will be reviewed, and replacement pieces will be sent at our discretion. For warranty information, visit <https://tiny.cc/SunnydazeWarranty>

If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at <https://tiny.cc/SunnydazeContact>

METAL HOSE HOLDER

Hose not included.

Review all information before using this product. Save this manual for future reference.

GENERAL USE: Place on a flat, level surface. Avoid storing hoses full of water. Ensure the lid is secure between uses.

MOVING: Always lift the unit when moving it; never drag or slide it as doing so will damage the finish and cause the unit to rust. Slowly and gently set the unit down to prevent breakage.

CLEANING: Wipe surfaces with a dry, soft cloth. Do not use chemicals, polish or abrasive materials when cleaning this product.

WINTER CARE & STORAGE: Avoid extreme temperatures and storing indoors during periods of freezing weather is recommended. To prevent damage, empty and/or store indoors during freezing temperatures.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with the product or it was damaged during transit, please contact our customer service team through one of the methods mentioned at the top of the page. Please have the item number and order information ready to expedite response time.

⚠️ WARNING: Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

