

# Whistle®

## Whistle®

### Multi-Purpose Powder Detergent

Whistle® Multi-Purpose Powder Detergent is an effective multi-surface cleaner for floors, counters, walls, appliances and other hard surfaces. Versatile powder formula can also be used in washing machines to lift out tough dirt and oil stains while leaving the laundry smelling fresh and clean.

#### Features & Benefits

- Excellent detergent cleaner for tough soils on floors, including stains on concrete
- Versatile product that can be used as a multi-surface cleaner and a laundry detergent
- Available in a resealable, water resistant pail with a measuring cup
- Specifically designed for the institutional environment
- Powder formula is easy to dispense and dilute
- Leaves laundry smelling fresh and clean

#### Applications

- After diluting in water, can be used on almost all washable surfaces: walls, floors, woodwork, concrete, cabinets, counters, laminated plastic, ceramic tile, aluminum, stainless steel, chrome, appliances, sinks, refrigerators, bathtubs, showers, painted woodwork, tools, boats, and bathroom fixtures
- Can also be used as a laundry detergent in home style or industrial washing machines





### Use Instructions

#### Master Use Instructions:

- 1 scoop = 4oz

#### FLOORS

- Use 1/2 scoop of detergent per average four gallon mop bucket of hot water. Use more for large buckets or hard water. Mop floor. Rinse. Position wet-floor signs around area to be cleaned.

**NOTE:** Floors will be slippery when wet or contaminated with foreign materials. Promptly clean up spills and foreign materials.

#### OTHER HARD SURFACES

- Use 1 scoop of detergent per two gallon pail of hot water. Wash surface with sponge or cloth. Rinse if needed.

#### LAUNDRY USE INSTRUCTIONS

- Measure - Use one scoop measured to the fill line for normal loads and use 1-1/2 scoops for large or heavily soiled loads
- Start Machine - Start water and add detergent to your machine before clothes. If you use bleach, add it 5 minutes after wash cycle begins for best results. Detergent works in all temperatures. Look for recommended wash temperature on garment labels. If they are not available follow temperature directions.
- HOT - white cottons and colorfast light colors
- WARM - permanent press and bright colors
- COLD - colors that fade or bleed


#### PRE-TREATING

- Add 1 scoop to your washer with warm water
- Soak for 30 minutes or overnight
- Drain machine, launder as usual

#### COLORFAST TEST

- Dip a hidden corner of fabric in detergent and hot water
- Rinse and let dry
- Proceed if color is unchanged

Technical data	Whistle® Multi-Purpose Powder Detergent
Color/Form	White, Powder
pH	10.1
Scent	Citrus
Shelf Life	2 Years

Product	Pack size	Dilution	Product code	
Whistle® Multi-Purpose Powder Detergent	1 x 19 lb. / 8.62 kg Pail (76 loads per unit)	Ready-to-use	CBD95729888	

### Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at [www.diversey.com](http://www.diversey.com) or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate. Please refer to the Diversey HazMat Library, only available through Internet Explorer, <http://naextranet.diversey.com/dot/>, for up-to-date shipping information.