



LYSOL®

Advanced Deep Clean All Purpose Cleaner

Lysol advanced deep clean all purpose cleaner helps to deliver fresh, deep-cleaned and sanitary surfaces. The advanced formulation powers through the toughest cleaning jobs, cutting through tough grease and soap scum, and eliminating 99.9% of viruses and bacteria, when used as directed.*

Features & Benefits

- Kills 99.9% of germs in 10 seconds, when used as directed
- Destroys tough grease and grime, while quickly cutting through stubborn stains and spills
- Two minute disinfection for bacteria and viruses, including cold and flu viruses, salmonella, pseudomonas, HIV-1 (aids virus), hepatitis B virus, and other illness causing germs on hard, nonporous surfaces, when used as directed
- Advanced formulation offers powerful grease-cutting performance, with a lemon breeze scent



* When used as directed.



**LYSOL®**

Advanced Deep Clean All Purpose Cleaner

DIRECTIONS FOR USE:

It is a violation of Federal law to use this product in a manner inconsistent with its labeling.

To Operate: Turn nozzle counter clockwise to preferred usage.

To Operate: Turn nozzle to ("ON") (desired) position.

To Refill (Bottle): Remove trigger sprayer. Pour in product from refill container and replace trigger.

To Refill (Bottle): Remove trigger unit from empty bottle and attach to new bottle.

To Clean (/ Deodorize) (/ Remove Allergens††): (Spray) (Apply to) surface until thoroughly wet. Wipe with a clean cloth or sponge.

To Clean (Lime Scale)(Soap Scum)(and)(Greasy Soil): Allow product to sit 15-20 seconds to penetrate soil before wiping clean. Repeat if necessary.

To Clean (Household) (and) (Kitchen) Surfaces: (Spray) (Apply to) dirty (soiled) area, wipe clean.

To Sanitize / Disinfect: Pre-clean surface. (Spray) surface until thoroughly wet.

To Sanitize: Leave for (10) (30) seconds before wiping. To Disinfect: Leave for (2) (10) minutes before wiping.

To Control (and Prevent) (the Growth of) Mold & Mildew: Apply to pre-cleaned surface. Let surface remain wet for 3 minutes and then allow to air dry. Repeat application at weekly intervals or when mold and mildew growth appears.

Dual Nozzle Cleaning Directions:

To Clean Baked-on Stains & Grease: Close nozzle (window)(hinge-door) for foam. Spray foam on surface until thoroughly wet, and (leave on) (let sit on) (allow to sit on) baked-on stains or grease. Wipe with a clean cloth or sponge.

To Clean Everyday Messes: Open nozzle (window)(hinge-door) for spray. Apply to surface until thoroughly wet. Wipe with a clean cloth or sponge.

To Disinfect Toys: Use only on hard non-porous surfaces. Pre-clean surface(s). (Apply to surface until thoroughly wet.) (Thoroughly wet surface) Allow (surface) to remain wet for (2) (10) minutes before wiping. Rinse thoroughly with potable water after use.

Technical data	LYSOL® Advanced Deep Clean All Purpose Cleaner
Color/Form	Clear, Aerosol
Shelf Life	2 Years
EPA Registration #	777-91

Product	Pack size	Dilution	Product code
LYSOL® Advanced Deep Clean All Purpose Cleaner - Lemon Breeze	12 x 32 oz./946 mL	Ready-to-use	CB003510

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate.