

**ASSEMBLY INSTRUCTIONS** 



### PARTS AND FITTING PACKAGING DETAIL






BOX #3 D. SIDE RAILS E. CENTER SUPPORT F. SUPPORT LEG	2 PCS 1 PC 5 PCS
D	

#### FULLY ASSEMBLED




HARDWARE KIT PACKED IN BOX #2			
NO.	DESCRIPTION	IMAGE	QTY
1	THREADED BOLT (8x60mm)		8 PCS
2	ARC WASHER (2x14x26mm)	0	8 PCS
3	LOCK WASHER (M10)	Ø	8 PCS
4	HEX NUT (M8)		8 PCS
5	WRENCH	ß	1 PC
6	WOOD SCREW (4x35mm)	Samuel Control	2 PCS
7	WOOD SCREW (4x25mm)		9 PCS
8	ALLEN KEY		1 PC




**ASSEMBLY INSTRUCTIONS** 








## STEP 3



### **STOP**


- $\bullet$  IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 4, 5,6 & 7 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT.
- •IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 4




**ASSEMBLY INSTRUCTIONS** 







## STEP 6



### STEP 7




#### ASSEMBLY COMPLETE

### INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your space and locate the leveler under each leg support (F).

Turn the leveler counter-clockwise to extend and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.



- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

#### **ASSEMBLY INSTRUCTIONS**





AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.

PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.


THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

C. SLAT ROLL : 1 SET \*WOOD SCREW (4x35mm) :2 PCS E. CENTER SUPPORT : 1 PC \*WOOD SCREW (4x25mm) :9 PCS

F. SUPPORT LEG : 5 PCS

#### **STEP #1:**


USE ALLEN KEY (8) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.




**ASSEMBLY INSTRUCTIONS** 



### PARTS AND FITTING PACKAGING DETAIL






BOX #3 D. SIDE RAILS E. CENTER SUPPORT F. SUPPORT LEG	2 PCS 1 PC 5 PCS	
D	E	

### FULLY ASSEMBLED





HARDWARE KIT PACKED IN BOX #2			
NO.	DESCRIPTION	IMAGE	QTY
1	THREADED BOLT (8x60mm)		8 PCS
2	ARC WASHER (2x14x26mm)	0	8 PCS
3	LOCK WASHER (M10)	Ø	8 PCS
4	HEX NUT (M8)	6	8 PCS
5	WRENCH	S	1 PC
6	WOOD SCREW (4x35mm)	Samuel Control	2 PCS
7	WOOD SCREW (4x25mm)	Spanner of the same of the sam	9 PCS
8	ALLEN KEY		1 PC



**ASSEMBLY INSTRUCTIONS** 











- •IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 4, 5, 6 & 7 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT. •IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 4




ASSEMBLY INSTRUCTIONS






## STEP 6



### STEP 7




#### ASSEMBLY COMPLETE

### INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your space and locate the leveler under each leg support (F).

Turn the leveler counter-clockwise to extend and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.



- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

#### **ASSEMBLY INSTRUCTIONS**





AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.

PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.


THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

C. SLAT ROLL : 1 SET \*WOOD SCREW (4x35mm) :2 PCS E. CENTER SUPPORT : 1 PC \*WOOD SCREW (4x25mm) :9 PCS

F. SUPPORT LEG : 5 PCS

#### **STEP #1:**

USE ALLEN KEY (8) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.



**ASSEMBLY INSTRUCTIONS** 



**QTY** 

8 PCS

8 PCS

8 PCS

8 PCS

1 PC

4 PCS

12 PCS


12 PCS


**12 PCS** 

12 PCS

1 PC

### PARTS AND FITTING PACKAGING DETAIL






BOX #2


BOX #3

D. SIDE RAILS
E. CENTER SUPPORT
F. SUPPORT LEG
G. LEFT MATTRESS SPACER
H. RIGHT MATTRESS SPACER
1 PC
1 PC

HARDWARE KIT PACKED IN BOX #2




### **FULLY ASSEMBLED**





ALLEN KEY







11


**ASSEMBLY INSTRUCTIONS** 








- •IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 4, 5, 6, 7 & 8 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT. •IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 4




ASSEMBLY INSTRUCTIONS











**ASSEMBLY INSTRUCTIONS** 










ASSEMBLY COMPLETE

#### INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your space and locate the leveler under each leg support (F).

Turn the leveler counter-clockwise to extend and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.



- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

#### **ASSEMBLY INSTRUCTIONS**





AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.


PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.

THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

: 1 SET C. SLAT ROLL \*WOOD SCREW (4x35mm) :4 PCS : 2 PCS \*WOOD SCREW (4x25mm) E. CENTER SUPPORT :12 PCS \*ALLEN BOLT (6x60mm) :12 PCS F. SUPPORT LEG : 10 PCS \*LOCK WASHER (M9) :12 PCS G. LEFT MATTRESS SPACER : 1 PC \*FLAT WASHER (M6) :12 PCS H. RIGHT MATTRESS SPACER : 1 PC

#### **STEP #1:**


USE ALLEN KEY (11) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.





**ASSEMBLY INSTRUCTIONS** 



### PARTS AND FITTING PACKAGING DETAIL











BOX #2







HARDWARE KIT PACKED IN BOX #2			
NO.	DESCRIPTION	IMAGE	QTY
1	THREADED BOLT (8x60mm)		8 PCS
2	ARC WASHER (2x14x26mm)	0	8 PCS
3	LOCK WASHER (M10)	Ø	8 PCS
4	HEX NUT (M8)		8 PCS
5	WRENCH	S	1 PC
6	WOOD SCREW (4x35mm)	Sammer .	4 PCS
7	WOOD SCREW (4x25mm)	Spanner.	12 PCS
8	ALLEN KEY		1 PC



**ASSEMBLY INSTRUCTIONS** 











- $\bullet$  IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 4, 5, 6 & 7 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT.
- •IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 4




**ASSEMBLY INSTRUCTIONS** 








## STEP 6



### STEP 7




#### ASSEMBLY COMPLETE

### INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your space and locate the leveler under each leg support (F).

Turn the leveler counter-clockwise to extend and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.



- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

#### **ASSEMBLY INSTRUCTIONS**





AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.

PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.

THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

C. SLAT ROLL : 1 SET \*WOOD SCREW (4x35mm) :4 PCS E. CENTER SUPPORT : 2 PCS \*WOOD SCREW (4x25mm) :12 PCS

F. SUPPORT LEG : 10 PCS

#### **STEP #1:**

USE ALLEN KEY (8) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.

