

Assembly Guide



Bush
FURNITURE




If you're having any difficulty during assembly of this product, don't hesitate to call us at
1-800-950-4782.

Our customer service experts are trained to provide step-by-step instruction and can easily replace any missing or damaged parts.

**Representatives are available Monday-Friday
from 8:30 a.m. to 7:30 p.m. (ET)**

Media Chest/ Sideboard/ Credenza



Lot Code #

Instruction Sheet Number A206435B

Keep manual for future reference.

For best results, keep these tips in mind:

- ① We know you want to finish this assembly as quickly as possible, but trust us: you'll have a better experience if you take it one step at a time.
- ② Give yourself some room to work near where you want the fully assembled product.
- ③ If your floor isn't carpeted, assemble this product on the empty carton to avoid scratching.
- ④ Do you have a friend who owes you a favor? Some steps may go a little easier with a second set of hands.

DOs

- ✓ Use a #2 Phillips head screwdriver (or other handheld tools as indicated)
- ✓ Wear safety glasses at all times during assembly
- ✓ Carefully follow the instructions in this guide and complete all steps in order
- ✓ Give us a call if you're having trouble with a particularly tricky step

DON'Ts

- ✗ We know power tools are quick and easy, but you shouldn't use them when assembling this product (unless otherwise specified)
- ✗ Never move your furniture with items inside or resting on the surface
- ✗ Do not attempt to use this product before all steps have been completed



Watch assembly videos right on your phone or computer!



Some steps include QR codes that link to helpful videos. Watch out for the icon on the left! Simply open up your smartphone camera to scan the code.

(Users of older smartphones may need to install a QR Reader.)

SCAN HERE



FOR VIDEOS

Or visit <https://www.bushfurniture.com/CustomerService/HowtoAssemble.aspx>

IMPORTANT SAFETY INFORMATION



PLEASE READ WARNINGS

Improper use can cause safety hazards, or damage to your furniture and household items.

Warning	Do	Don't	Why it's important
Serious injury or death may occur.	• Only place flat screen TVs on this product • Assemble following all instructions using all indicated parts and hardware provided. • For use with televisions weighing 45 lbs (20.4 kg) or less and having a diagonal screen size of 55 inches (1397 mm) or less • Install every indicated nail and/or screw. • Verify Furniture is stable on it's own. • Place heaviest items in the lower drawers or shelves. • Always install tipover restraint hardware provided. • Remove items that might tempt kids to climb, such as toys and remote controls from the top and upper shelves of furniture.	• Do not move unit when loaded. • Do not exceed the maximum load limits stated in the instructions. • Do not allow children to stand, climb, or hand on furniture.	Improper assembly, use or loading can lead to product instability, tipover, or collapse.

IMPORTANT SAFETY INFORMATION



PLEASE READ WARNINGS

Improper use can cause safety hazards, or damage to your furniture and household items.

Advertencia	Hacer	No	Por qué es importante
Pueden producirse lesiones graves o la muerte.	• Coloque únicamente televisores de pantalla plana sobre este producto. • Realice el montaje siguiendo todas las instrucciones y utilizando todas las piezas indicadas y los herrajes suministrados. • Para televisores que pesen 20,4 kg (45 libras) o menos y tengan una diagonal de pantalla de 1397 mm (55 pulgadas) o menos. • Instale todos los clavos y/o tornillos indicados. • Compruebe que el mueble sea estable por sí mismo. • Coloque los objetos más pesados en los cajones o estantes inferiores. • Instale siempre los herrajes de antivuelco suministrados. • Retire los objetos que puedan tentar a los niños a trepar, como juguetes y mandos a distancia, de los estantes superiores y superiores del mueble.	• No mueva la unidad cuando esté cargada. • No supere los límites máximos de carga indicados en las instrucciones. • No permita que los niños se pongan de pie, trepen o se cuelguen de los muebles.	El montaje, uso o carga inadecuados pueden provocar inestabilidad, vuelco o colapso del producto.

IMPORTANT SAFETY INFORMATION



PLEASE READ WARNINGS

Improper use can cause safety hazards, or damage to your furniture and household items.

Avertissement	À faire	À ne pas faire	Pourquoi c'est important
Pueden producirse lesiones graves o la muerte.	• Seuls les téléviseurs à écran plat conviennent à ce produit. • Assembler en suivant toutes les instructions et en utilisant toutes les pièces et la quincaillerie incluses. • Pour une utilisation avec des téléviseurs pesant 45 lb (20,4 kg) ou moins et ayant une diagonale d'écran de 55 po (1397 mm) ou moins • Installer tous les clous et/ou toutes les vis. • Assurez-vous que le meuble soit stable par lui-même. • Placer les objets les plus lourds sur les tablettes ou dans les tiroirs du bas. • Toujours installer le matériel de fixation mural inclus. • Retirer les objets qui pourraient inciter les enfants à grimper comme les jouets et les télécommandes des tablettes supérieures et du dessus du meuble.	• Ne pas déplacer le meuble lorsqu'il est chargé. • Ne pas dépasser les limites de poids maximales indiquées dans les instructions. • Ne pas laisser les enfants se tenir sur les meubles, y grimper ou s'y suspendre.	Un assemblage, une utilisation ou un chargement incorrects peuvent entraîner l'instabilité, le basculement ou l'effondrement du produit.

IMPORTANT SAFETY INFORMATION




PLEASE READ WARNINGS

Improper use can cause safety hazards, or damage to your furniture and household items.

This product meets tip stability safety specification for clothing storage units. ASTM F2057-19.














Ce produit est conforme à la norme sur les spécifications de sécurité en matière de stabilité pour les unités de rangement de vêtements. ASTM F2057-19.

Este producto es conforme a la norma relativa a las especificaciones de estabilidad en materia de seguridad aplicables a los muebles para guardar ropa. ASTM F2057-19.



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


Fasteners are shown actual size.



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


Hardware not to scale.

Q184100




[3]

H214973




[2]

H192351



[1]

H100446




[6]

3 Drawer Interlock


Drawer Bracket

H215406



[1]

H23604




[4]

Bumper (10) per pack


Shelf Pin

H215407



[1]


H126396



[4]

Bumper (10) per pack

Shelf Pin Sleeve




[4]



[8]

Cover Cap




[4]

Foot

TIPOVER RESTRAINT HARDWARE


SUGERENCIA SOBRE HARDWARE DE RETENCIÓN
MATÉRIEL DE RETENUE SUR LE SUPPORT

H107572



[1]


H181419



[1]

Toggle Bolt


H181412



[2]


Connecting Plate

H181411



[1]

H181434



[1]

#10 x 2"




Have an assembly question or need a replacement part? Just call

1-800-950-4782, we are here to help.

STEP 1

Prepare Panels

A206435B





Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 2

Assemble Panels


A206435B

H218835 [12]
(Black) #8 x .5"




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

H26053



[12]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Scan QR Code to
Watch Video on:




How to Separate
and Install Drawer
Slides

Slides Must Be Separated Before Assembly. After Separated, Set Aside Until Needed for Assembly.


Las diapositivas deben separarse antes del montaje.
Después de la separación, déjelo a un lado hasta que sea necesario.

Les glissières doivent être séparées avant l'assemblage.
Après la séparation, mettez de côté jusqu'au moment de l'assemblage.




STEP 1: Extend Slide

Extender la diapositiva
Extendre la diapositive




STEP 2: Push Lever UP

Empujar hacia arriba
Lever le levier



STEP 3: Remove Runner

Quitar el corredor
Enlever le coureur



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 5

Attach Hardware

A206435B

Scan QR Code to
Watch Video on:



How to Separate
and Install Drawer
Slides

H29206



Bumper

[3] Q184100


H192100



#8 x 1/2"


[12]

H23480



#8-32 x 7/8"


[6]



10" Slide Runner


[6]

*
Orientation
Orientación
L'orientation



Handle

[3]




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 6

Prepare Panel

A206435B



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 7

Prepare Panel


A206435B

Scan QR Code to
Watch Video on:



How to Separate
and Install Drawer
Slides

Q184100



10" Slide Mount

[3]

*


Orientation
Orientación
L'orientation

H192260



[6]

Euro 10mm




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 8

Prepare Panels / Rails


A206435B

H171556



Quickfit TL4

[6]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 9

Assemble Panels


A206435B

Scan QR Code to
Watch Video on:



How to Tighten
KD Cams



Team Lift



H181468US



[2]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 10

Prepare / Assemble Panels


A206435B

Scan QR Code to
Watch Video on:



How to Tighten
KD Cams


H181468US



KD Cam3000

[2]


H171556




Quickfit TL4

[2]




1



2




3



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

H23370  [2]
#10 x 1-1/4"



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 12

Assemble Panels

A206435B

Scan QR Code to
Watch Video on:




How to Tighten
KD Cams

H181468US




KD Cam3000

[2]





Cover Cap

[2]



Team Lift




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


STEP 13

Prepare Panel

A206435B

H23370  [6]
#10 x 1-1/4"

H171556  [2]
Quickfit TL4



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 14

Assemble Panels

A206435B

Scan QR Code to
Watch Video on:





How to Tighten
KD Cams

H181468US



[2]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 15

Attach Hardware


A206435B

H192100  [1]
#8 x 1/2"


H192351

[1]

3 Drawer Interlock



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.



STEP 17

Assemble Panels

A206435B

Scan QR Code to
Watch Video on:






How to Tighten
KD Cams

H181468US



[2]




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 18

Prepare Panel


A206435B



Foot

[4]

H143460




[4]

#12 x 4"

H23119


(Black)



[8]


#10 x 5/8"

H171556



[6]

Quickfit TL4



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 19

Assemble Panels

A206435B

Scan QR Code to
Watch Video on:




How to Tighten
KD Cams




H181468US



[6]



[2]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 20

Prepare / Assemble Panels


A206435B

H38169




[4]

Wood Dowel 8 x 30



Finished edge
Borde acabado
Bord fini




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 21

Prepare Panel



A206435B

H72988



KD Bolt

[4]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 22

Assemble Panels


A206435B

Scan QR Code to
Watch Video on:



How to Tighten
KD Cams


Team Lift



H181468US



KD Cam3000




Cover Cap


[4]

[4]


1





2



3



4



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Team Lift




With assistant, carefully flip unit over.

Con el asistente, voltee cuidadosamente la unidad.


Avec l'assistant, retourner soigneusement l'unité.

H34174



Nail 19mm


[40]



Safety glasses

Gafas de seguridad

Lunettes de protection



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.



FOLLOW THESE STEPS TO SECURE UNIT TO THE WALL USING TIPOVER RESTRAINT

SIGA ESTOS PASOS PARA FIJAR LA UNIDAD A LA PARED UTILIZANDO LA PUNTA SOBRE EL SEGURO
SUIVEZ CES ÉTAPES POUR SÉCURISER L'APPAREIL AU MUR EN UTILISANT LA PRISE DE RETENUE

1. Place unit in desired location.
2. Locate wall stud nearest unit center. FIG A
3. On wall, mark center of stud location 1" below top of unit. FIG A
4. If a wall stud cannot be located mark hollow wall at unit center. FIG A
5. On back of unit, mark corresponding location 3/8" below top of unit. FIG B

1. Coloque la unidad en el lugar deseado.
2. Localice pie derecho de pared centro de unidad más próxima.
3. En la pared del, marque el centro de la ubicación del montante 1 "abajo la parte superior de la unidad.
4. Si un poste de la pared no se puede localizar marcar pared hueca en el centro de la unidad.
5. En el dorso de la unidad, marque la ubicación 3/8 correspondiente abajo la parte superior de la unidad.


1. Placez l'unité à l'endroit désiré.
2. Localiser centre d'unité la plus proche de la paroi Stud.
3. Sur le mur, centre de emplacement du montant 1 "ci-dessous dessus de l'appareil de la marque.
4. Si un montant de mur ne peut pas être situé marquer mur creux au centre de l'unité.
5. Le dos de l'appareil, marquer l'emplacement 3/8 correspondant ci-dessous dessus de l'appareil.



3/8" (10mm)
MARK BACK OF PRODUCT BELOW TOP
MARQUE DETRÁS DEL PRODUCTO, POR DEBAJO DEL TOP
MARQUER LE PRODUIT, CI-DESSOUS

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

WALL STUD ATTACHMENT




Drill 1/8" hole 2" deep at mark on wall.

Taladro 1/8 "agujero 2" de profundidad en la marca en la pared.

Percer 1/8 "trou de 2" de profondeur à la marque sur le mur.


H181434



[1]


#10 x 2"

H181412




[1]

Connecting Plate




Drywall
Paneles de yeso
cloisons sèches



Wood stud
Montante de madera
Stud bois

HOLLOW WALL ATTACHMENT




Drill 1/2" hole 1" deep at mark on wall.

Taladro 1/2 "agujero 1" de profundidad en la marca en la pared.

Percer 1/2 "trou de 1" de profondeur à la marque sur le mur.


H181419



[1]


Toggle Bolt

H181412




[1]

Connecting Plate




Drywall
Paneles de yeso
cloisons sèches

Pull while tightening
Jale mientras aprieta
Tirer tout en resserrant



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


H107572



[1]


#8 x 1-1/2"

H181412



[1]



Connecting Plate



Drill 1/8" hole 1" deep at mark on unit.

Taladro 1/8 "agujero de 1" de profundidad en la marca de la unidad.




Percer 1/8 "trou 1" de profondeur à la marque sur l'unité.



H181411

Nylon Cable Tie

[1]



Correct
Correcto
Corriger

Pull to verify lock
Tire para verificar cerradura
Tirez pour vérifier serrure

Use replacement cable tie with minimum breaking strength of 120lbs.

Utilice reemplazo empate Cable con resistencia a la rotura mínima de 120 libras.

Utilisez remplacement Attache de câble avec une force de rupture minimale de 120 lbs.

Have an assembly question or need a replacement part? Just call



1-800-950-4782, we are here to help.

Scan QR Code to
Watch Video on:





How to Adjust
Door Hinges




Team Lift



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.



Door Adjustment
Ajustement des portes
Ajuste de la puerta




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 29

Insert Component

A206435B


H23604



[4]


Shelf Pin

H126396




[4]

Shelf Pin Sleeve



x4



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Scan QR Code to
Watch Video on:




How to Separate
and Install Drawer
Slides

TOP DRAWER INSTALLATION


INSTALACION DEL TIRADOR SUPERIOR
INSTALLATION DE TIROIR

Team Lift




INSTALL DRAWER WITH WARNING LABEL, IN TOP POSITION

INSTALAR CON LA ETIQUETA DEL CAJÓN
ADVERTENCIA EN LA POSICIÓN SUPERIOR
INSTALLER LE TIROIR AVEC L'ÉTIQUETTE
D'AVERTISSEMENT, EN POSITION SUPÉRIEURE




1. MOVE SLIDE TO FORWARD MOST POSITION

MOVER DIAPOSITIVA HACIA ADELANTE MÁS POSICIÓN
DÉPLACER LA DIAPOSITIVE VERS L'AVENIR



2. BOTH RIGHT AND LEFT SIDES

AMBOS LADOS DERECHO E
IZQUIERDO
LES DIFFERENTS ET GAUTS



3. INSERT DRAWER, CAREFULLY POSITION SLIDE RUNNER INTO MOUNT. OPEN AND CLOSE TO CHECK DRAWER FUNCTION.

INSERT CAJÓN, DESLICE CON CUIDADO POSICIÓN EN MONTAJE CORREDOR. SE ABREN Y CIERRAN PARA CONTROLAR LA FUNCIÓN CAJÓN.
INSERT TIROIR SLIDE RUNNER EN ATTENTIVEMENT POSITION MONT. OUVERT ET PROCHE DE LA FONCTION DE VOIR TIROIR.

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Scan QR Code to
Watch Video on:





How to Separate
and Install Drawer
Slides

MIDDLE DRAWER INSTALLATION

SEGUNDA INSTALACIÓN DEL CAJÓN
DEUXIÈME INSTALLATION DE TIROIR


Team Lift



1. CLOSE ALL DRAWERS
CERRAR TODOS LOS CAJONES
PROCHE TOUTES LES TIROIRS


2. MOVE SLIDE TO FORWARD MOST POSITION
MOVER DIAPOSITIVA HACIA ADELANTE MÁS POSICIÓN
DÉPLACER LA DIAPOSITIVE VERS L'AVENIR

3.



BOTH RIGHT AND LEFT SIDES

AMBOS LADOS DERECHO E IZQUIERDO
LES DIFFERENTS ET GAUTS



4.

INSERT DRAWER, CAREFULLY POSITION SLIDE RUNNER INTO MOUNT. OPEN AND CLOSE TO CHECK DRAWER FUNCTION.

INSERT CAJÓN, DESLICE CON CUIDADO POSICIÓN EN MONTAJE CORREDOR. SE ABREN Y CIERRAN PARA CONTROLAR LA FUNCIÓN CAJÓN.
INSERT TIROIR SLIDE RUNNER EN ATTENTIVEMENT POSITION MONT. OUVERT ET PROCHE DE LA FONCTION DE VOIR TIROIR.

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Scan QR Code to
Watch Video on:





How to Separate
and Install Drawer
Slides

BOTTOM DRAWER INSTALLATION



INSTALACIÓN FONDO DEL CAJÓN
BAS INSTALLATION DE TIROIR

Team Lift



1. **CLOSE ALL DRAWERS**
CERRAR TODOS LOS CAJONES
PROCHE TOUTES LES TIROIRS

2. **MOVE SLIDE TO FORWARD MOST POSITION**
MOVER DIAPOSITIVA HACIA ADELANTE MÁS POSICIÓN
DÉPLACER LA DIAPOSITIVE VERS L'AVENIR



3. **BOTH RIGHT AND LEFT SIDES**
AMBOS LADOS DERECHO E IZQUIERDO
LES DIFFERENTS ET GAUTS

4. **INSERT DRAWER, CAREFULLY POSITION SLIDE RUNNER INTO MOUNT. OPEN AND CLOSE TO CHECK DRAWER FUNCTION.**

INSERT CAJÓN, DESLICE CON CUIDADO POSICIÓN EN MONTAJE CORREDOR. SE ABREN Y CIERRAN PARA CONTROLAR LA FUNCIÓN CAJÓN.
INSERT TIROIR SLIDE RUNNER EN ATTENTIVEMENT POSITION MONT. OUVERT ET PROCHE DE LA FONCTION DE VOIR TIROIR.

Have an assembly question or need a replacement part? Just call







1-800-950-4782, we are here to help.

Scan QR Code to
Watch Video on:



How to Adjust
Drawer Fronts

DRAWER FRONT VIEW



REQUIRED TOOL: PHILLIPS SCREWDRIVER

HERRAMIENTA REQUERIDA: DESTORNILLADOR PHILLIPS
OUTIL REQUIS: TOURNEVIS CRUCIFORME



1. LOOSEN SCREWS.
2. ADJUST DRAWER FRONTS.
3. TIGHTEN SCREWS.

1. Afloje los tornillos
2. Ajustar frentes de cajón
3. Apriete los tornillos

1. Desserrer les vis
2. Ajuster les façades des tiroirs
3. Serrer les vis


Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Scan QR Code to
Watch Video on:



How to Clean
the Surface




Gently clean surfaces with a damp sponge eraser.






Congratulations! You are all done. If
you have any questions or concerns,
please call.

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STV148SG		
LABEL	QTY	NUMBER
A	1	W206436
B	1	W206437
C	1	W206438
D	1	W206439
E	1	W206440
F	1	W206441
G	3	W206519
H	1	W222199
J	3	W192869
K	2	W206443
L	1	W206445
M	1	W206444
N	1	W206685
O	1	W206833
P	6	W192210
Q	3	W191038
R	3	W184158






STV148FW		
LABEL	QTY	NUMBER
A	1	W206446
B	1	W206447
C	1	W206448
D	1	W206449
E	1	W206450
F	1	W206451
G	3	W206520
H	1	W222197
J	3	W192869
K	2	W206453
L	1	W206455
M	1	W206454
N	1	W206686
O	1	W206834
P	6	W192210
Q	3	W191038
R	3	W184158






PARTS LIST

A206435B

STV148PG		
LABEL	QTY	NUMBER
A	1	W206456
B	1	W206457
C	1	W206458
D	1	W206459
E	1	W206460
F	1	W206461
G	3	W206521
H	1	W222198
J	3	W192869
K	2	W206463
L	1	W206465
M	1	W206464
N	1	W206687
O	1	W206835
P	6	W192210
Q	3	W191038
R	3	W184158



STV148AG		
LABEL	QTY	NUMBER
A	1	W206466
B	1	W206467
C	1	W206468
D	1	W206469
E	1	W206470
F	1	W206471
G	3	W206522
H	1	W222196
J	3	W192869
K	2	W206473
L	1	W206475
M	1	W206474
N	1	W206688
O	1	W206836
P	6	W192210
Q	3	W191038
R	3	W184158



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.