

If your product is missing parts, please call Customer Support at (800) 225-7593 or email support@gldgames.com



## Wall Mounting Assembly Kit

Item #: 37-0136



▲ **CAUTION!** BEWARE OF ELECTRICAL WIRES AND WATER PIPES WHEN DRILLING THROUGH YOUR WALL.

▲ CAUTION! CHOKING HAZARD: THIS PRODUCT INCLUDES SMALL OBJECTS NOT SUITABLE FOR CHILDREN UNDER 3 YEARS OLD.



## Great Lakes Dart Mfg., Inc.


S84 W19093, Enterprise Drive Muskego, WI 53150 USA (262) 679-8730 or (800) 225-7593 support@gldgames.com www.gldproducts.com



All trademarks whether or not designated by ™ or <sup>®</sup> are owned by Great Lakes Dart Mfg., Inc. unless otherwise noted.


## DIAGRAM #1 P' 1/\* or 2.93m Port cetter of Bullsage to Throw Line (ror 2.7mm for to cetter of Bullsage rom foot to cetter of Bullsage ref or 1.7mm foot to cetter of Bullsage ref or 1.7mm foot to cetter of Bullsage From foot co cetter of Bullsage From foot

 Begin by marking off the proper height from the floor on your wall (5'8" or 1.73m). The bottom of the u-shaped channel should be at this height. (4'6" or 1.37m for wheelchair user).




 Drive the Dartboard Mounting Screw into the pre-drilled center hole, leaving space to hang the dartboard onto the Mounting Bracket.

## DIAGRAM #2



 Apply the Mounting Feet to the backside of your dartboard, spaced evenly around the perimeter, driving the Stabilizer Screws into the proper spots.



- Use the two Bracket Mounting Screws to install the Mounting Bracket to your wall, using wall anchors if not positioned over a stud.
- Place the dartboard onto the Mounting Bracket and check for tightness against the wall. If the dartboard is wobbling, remove and tighten or loosen the Dartboard Mounting Screw as needed.