


SHIMANO

SUSTAIN

SA40XGFK



(51SF996H45X)

Please note that the number of adjusting washers may not be the same as shown in the exploded views.
(Adjustment will vary with each individual product.)

#	Part No.	RD No.	Description	#	Part No.	RD No.	Description	#	Part No.	RD No.	Description
1	14BWL		Drag Knob Assembly	44	10TJM	18208	Bearing Spacer	87	10SQA	22296	Idle Gear (Large)
2	14CC3		Spool Assembly	45	14BZG		Bail Assembly	88	141Q9		Main Shaft Assembly
3	10B8N	16931	Retainer	46	1018Z	17680	Washer	89	106VJ	15676	Oscillating Pawl
4	10K3C	20994	Key Washer B	47	10TPC	17681	Line Roller Support	90	1070D	16796	Washer
5	10R5H	22029	Drag Washer A	48	1009B	19876	Bail Spring Guide A Bush	91	100WX	19780	O Ring
6	1427B		Eared Washer	49	10SAN	19857	Bail Spring Guide A	92	1010C	20274	Oscillating Slider Bushing
7	10B9D	9910	Key Washer	50	101D9	18724	Bail Spring Guide A Collar	93	1010D	20285	Oscillating Pawl Cover
8	10BQF	17183	Drag Click Spring	51	10DMC	17817	Bail Spring	94	10LCT	18412	Screw
9	102H5	17184	Drag Click	52	107AB	17684	Bail Spring Guide B	95	1429B		Rear Protector
10	10TRB	17664	Screw	53	147C4		Bail Trip Lever	96	10RX2	20987	Screw
11	10BSL	17812	Spool Washer	54	14750		Bail Hold Support Guard	97	104PP	13274	Ball Bearing
12	13YXH		Spool Bearing Bushing	55	101D5	18732	Rotor Ring	98	1009S	22066	O Ring
13	10PN3	17667	Set Screw	56	10QXQ	19883	Friction Ring	99	1429H		Drive Gear
14	10KXC	8128	Ball Bearing	57	100WT	19777	Screw	100	1055H	19990	Screw
15	107V2	9833	Ratchet Spring	58	10S2L	18735	Roller Clutch Assembly	101	104PT	13189	Ball Bearing
16	107PS	11646	Drag Click Ratchet	59	1009Z	19866	O Ring	102	100W9	22285	Washer
17	103NY	20270	Spool Support	60	1009Y	19899	Roller Clutch Inner	103	14282		Bail Trip Strike
18	103GW	19989	Screw	61	100WY	19775	Screw	104	1009W	19886	Flange Water Proof
19	1076N	19926	Retainer	62	10DWD	19822	Bearing Retainer	105	10L6G	18221	Screw
20	10DY6	20262	Bearing Water Proof	63	10E7A	21224	Ball Bearing	106	14CC5		Side Cover Assembly
21	100RU	21006	Washer	64	1429G		Pinion Gear	107	14BX0		Handle Assembly
22	13YXF		Main Shaft Collar	65	10E37	20286	Washer	108	10PXV	17695	Handle Shaft Seal
23	10DXE	19781	O Ring	66	10GD9	20294	Washer	111	14CC6		Handle Shank Assembly
24	13YXE		Rotor Nut	67	104JT	13381	Ball Bearing	112	10PXZ	17698	Bushing
25	147BJ		Rotor Brim	68	13YXL		Idle Gear C Shaft	113	10RHC	20709	Handle Knob
26	14BZF		Rotor Assembly	69	10LZ6	10482	Screw	114	104FH	19745	Washer
27	10HE7	20069	Click Spring	70	108WH	0582	O Ring	115	10LFA	17700	Screw
28	106ZC	17415	Click Pin	71	1427T		Handle Screw Cap	116	1429D		Handle Knob Seal
30	10RNG	20990	Screw	72	145VK		Screw	121	10GEW	9912	Bearing Retainer
31	147BG		Counter Weight Cover	73	14BWW		Body	122	1427P		Idle Gear B Spring
32	101CC	20988	Screw	74	13YXQ		Oscillating Guide	123	14BWX		Idle Gear B Shaft
33	13YXC		Bail Arm Fin	75	100BH	22895	O Ring	124	14BX7		O Ring
34	14BWR		Bail Arm	76	14BX4		Worm Shaft				
35	10K96	18551	Washer	77	10K98	18201	Washer				
36	10TLM	18211	Screw	78	10ECK	18199	Washer				
37	10TLJ	18210	Screw	79	1009C	19976	Bushing				
38	10E44	20150	Collar	80	13YXP		Worm Shaft Retainer				
39	104VX	13269	Ball Bearing	81	10QG5	0647	Screw				
40	1009K	19837	Bushing	82	14BWW		Bushing				
41	1009E	19831	O Ring	83	10R5L	22058	Idle Gear				
42	1009A	19959	Line Roller	84	14AY4		Idle Gear Spring				
43	10RFZ	19839	Spacer	86	10R4Q	22061	Idle Gear C	501	13YXU		Bail Arm Fin (accessory)