


# CAPSULE

## OPEN FRAME 70" DRESSER



**#1870**

REVISED 08 DECEMBER 2016

[CAPSULEHOME.COM](http://CAPSULEHOME.COM)

# OPEN FRAME 70" DRESSER

## Furniture Anti-tipping Kit Installation

- To avoid possible scratching, assemble furniture on a soft surface (like a carpet or blanket).
  - Questions? Find us at [contact@capsulehome.com](mailto:contact@capsulehome.com)
  - Be careful not to over-tighten screws.
- 

Serious or fatal crushing can occur when furniture tips over on children. To help prevent tip-over, follow the steps below to install this anti-tipping strap.



### WARNING

**Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:**

- Install tipover restraint provided.
  - Place heaviest item in the lowest drawers.
  - Unless specifically designed to accommodate, do not set TVs or other heavy objects on top of this product.
  - Never allow children to climb or hang on drawers, doors, or shelves.
  - Never open more than one drawer at a time.
- (OR)
- Do not defeat or remove the drawer interlock system.

**Use of tip-over restraints may only reduce, but not eliminate, the risk of tip-over.**

This is permanent label. Do not attempt to remove!

---

\* Tools Needed (not included) : Phillips screwdriver


# OPEN FRAME 70" DRESSER

## Furniture Anti-tipping Kit Installation


---

### Hardware


---



H1 x 4  
1-1/2" Wood Screw



H2 x 2  
Bracket




H3 x 4  
Safety Strap

---

### Step 1

**Attach bracket to the wall with the 1-1/2" wood screws provided:**

- It is recommended that you locate a wall stud behind the furniture unit. If the wall stud is not used, a suitable "Hollow-Wall Anchor Bolt" (not provided) should be used in lieu of the wall stud.
- Position the wall bracket on the stud about 1" below the top of the furniture piece.
- Mark the position for the bracket placement on the wall and drill a pilot hole into the stud.
- Attach the bracket to the wall with the 1-1/2" screws provided.





# OPEN FRAME 70" DRESSER

## Furniture Anti-tipping Kit Installation

### Step 2

#### To Attach the safety straps:

- Move the furniture back to its final position.
- Thread 2 safety straps through both of the mounted brackets as shown in the illustration.
- Tighten the straps.
- Do not over tighten.



Assembly is complete.

## **Important:**

Make sure the brackets are securely attached to the wall stud and furniture frame, and the safety straps are tightened.

## **Warning:**

This product should not be a substitute for proper parental supervision which is the only proper deterrent to prevent improper use of this unit. The manufacturer assumes no liability for improper installation or excessive loads placed on the safety straps, bracket or mounting screws. This hardware will not insure against tipping.

## **Note:**

For taller or heavier pieces of furniture, two safety brackets might be installed.

## **!!PLEASE READ!**

DO NOT USE THE DRESSER IF IT IS DAMAGED OR BROKEN.