


Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <https://tiny.cc/SunnydazeWarranty>. If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at <https://tiny.cc/SunnydazeContact>

POLYRESIN BIRD BATH WITH SOLAR ADDRESS PLAQUE FC-127

Review all care information before using this product. Save this manual for future reference.



Ensure the solar panel is South facing



Do **NOT** place the solar panel in shaded areas



Inspect packaging to ensure all parts are accounted for before disposing of packing materials.
Save the packing slip.

PARTS	QTY.
Bird Bath	1
Ground Stake	2
Number Stickers	5 SETS



Clean the solar panel from time to time




Do **NOT** charge the solar panel behind glass

HOW SOLAR LIGHTS WORK

During the day, the solar panel converts solar energy into electricity and stores it in the rechargeable battery. At night, the lights turn on automatically via a light detecting sensor built into the solar panel. How long the lights illuminate will depend upon the location of the unit, weather conditions, and how much direct sunlight the solar panel is exposed to. Ensure the panel is switched to 'ON' while charging.

CHOOSING THE RIGHT LOCATION

- Select an outdoor location where the solar panel will receive at least 8 hours of full, direct sunlight each day. Ensure the solar panel will not become shaded by trees, shrubs or buildings throughout the day as this will lessen the charge of the battery and shorten the illumination time at night.
- Avoid locations with nighttime light sources nearby, such as street or porch lights. When the light detecting sensor receives too much ambient light, the lights will not illuminate.
- Only use on a flat, level surface.
- Be mindful of the type of plant used in the planter. The unit does not have drainage holes; soil could quickly become waterlogged during heavy rain. Leaks and/or run-off from planters could cause damage to the unit and to surfaces. Also avoid plants that will shade the solar panel.



APPLY STICKERS

Wipe the address plaque surface with a soft, lint-free cloth to ensure it is clean.

TIP: Before peeling the numbers off the sticker sheet, we recommend cutting the numbers out of the sticker sheet and placing them on the address plaque. This will help ensure proper alignment and spacing of the numbers.

Remove the number stickers from the paper backing and apply them to the plaque. Firmly rub the stickers with your fingers to ensure the adhesive has bonded with the address plaque.

INSTALLATION (OPTIONAL)

CAUTION: Do not push on the bowl or the birds when installing unit with ground stakes as doing so may crack or break the polyresin.

Clear any debris that may prohibit the stakes from being fully pressed into the ground, such as mulch, roots, stones or pavement.

Install the stakes into the bottom of the unit. Holding the unit from the sides, gently but firmly push downward until the stakes are fully inserted into the soil.


OPERATION

Press the power button to turn the solar panel 'ON'.

Place the unit in a sunny location.

First Time Use: The solar panel will require at least 8 hours of full, direct sunlight to fully charge the battery. Make sure the unit is turned 'ON' while charging.

As long as the battery has a sufficient charge, the lights will automatically illuminate when it gets dark.



ABOUT THE BATTERY

The battery, like all rechargeable batteries, has a limited life span, and become less efficient with repeated charge/discharge cycles. As the capacity of the battery reduces, the hours of operation will lessen, and the battery will need to be replaced.

IMPORTANT: Only use compatible rechargeable batteries; alternative batteries may be incompatible, which may damage the unit and will void the warranty.

Dispose of the batteries in accordance with local laws and regulations.

ACCESSING & CHANGING THE BATTERY

1. Press the power button to turn the solar panel 'OFF'.
2. Use a Phillips screwdriver to carefully remove the screws from the battery housing on the solar panel.
3. Gently remove the old battery.
4. Paying attention to the positive and negative terminals, gently insert a compatible new rechargeable battery.
5. Carefully reassemble the battery housing. Screws must be tight to prevent water from getting into the battery housing.
6. Fully charge the battery by place the unit in a location that will receive at least 8 hours of full, direct sunlight.

CARE & MAINTENANCE

FILLING & WATERING: Lightweight potting soil is recommended for filling the planter. Take care when watering, this unit does not have drainage holes.

MOVING: Always lift the unit from the bottom when moving it, never drag or slide it as doing so can damage the unit and/or surfaces. Slowly and gently set the unit down to prevent breakage.

CLEANING:

BIRD BATH: Clean the bird bath 1-2 time per week. Empty the old water, wash the bowl with clean water and a soft cloth. Thoroughly rinse with running water. Fill the bowl with clean water.

PEDESTAL: Remove loose dirt, cobwebs, and debris with a very soft-bristled brush, like a paintbrush. Gently rinse the unit using water only and allow it to air-dry. Dry the solar panel with a soft, lint-free cloth.

EXPOSURE: Over time, sunlight and weather elements will degrade and change the color of this product. Manufacturer is not liable for damage caused by exposure to weather elements.


WINTER CARE & STORAGE: Turn the solar panel off before storing the unit. Store in a warm, dry, indoor location. Cover to prevent dust build-up.

WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE APPLICATION OF CHEMICAL TREATMENTS, PROTECTIVE COATINGS, TOUCH-UP PAINT, OR CLEANING PRODUCTS.

TROUBLESHOOTING

- Ensure the power button is turned to the 'ON' position.
- Make sure the battery is installed correctly, observe polarity and ensure contact is good.
- This product is designed to only illuminate at night. Make sure the light sensor is not receiving too much ambient light.
- If the light only works for a short time, attempt a 'Boost Charge':
 - Turn the power 'ON' and let it charge in full, direct sunlight for at least 8 hours.
 - Turn the power 'OFF' at night to conserve the battery.
 - Repeat this process for 2-3 days. If the unit still does not work, the battery may need replacing.

! SAFETY STATEMENTS & WARNINGS !

- For outdoor use only.
 - For decorative purposes only. This item is not a toy.
 - Clean solar panels will absorb more sunlight. Keep the solar panel clean by gently wiping it with a soft, damp cloth.
 - Never use chemicals or abrasive materials to clean the unit.
 - Store in a dry, warm, indoor location during inclement weather and freezing temperatures.
 - Do not allow the unit to freeze. Freezing temperatures will damage the internal components.
 - Turn the unit off before storing it. Removing the battery during storage is recommended.
 - Only use compatible rechargeable batteries. Incompatible batteries may damage the unit and void the warranty.
-  This product uses a rechargeable battery. When the battery can no longer be used, it should be removed from the unit and recycled. The battery must not be incinerated or composted. Recycle the battery in accordance with local laws and regulations.

Any modification to the product or failure to follow recommended care will void the product warranty.

*If you experience issues with the product or it was damaged during shipping,
please contact our customer service team through one of the methods mentioned at the top of page 1.
Please have the item number and order information ready to expedite response time.*

! WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.