


ITEM# 85410





White Turned Leg Laptop Desk

Leick
Home
SINCE 1910

2219 S. 19th St.
Sheboygan, WI 53081
Ph: 920-451-4060
Fax: 920-451-4063
info@leickhome.com



Hardware List

Item	Description	Qty
a	 Bolt 5/16" *2"	8PCS
b	 Allen wrench	1PC
c	 Flat Washer 5/16" *19mm	8PCS
d	 Lock Washer	8PCS


Parts List

Item

Description

Qty


A



Top

1PC

B




Leg

4PCS

Assembly Instructions


step 1

Bolt on 4 legs with 8 bolts.



step 2

Adjust levelers on bottom of legs.



Wire management hole on back of desk: pull the disk out, run wires, and snap disk back in place.

