



OUTDOOR POLY RECLINING CHAISELOUNGE WITH WHEELS & CUP HOLDER

THANK YOU!

We appreciate you for choosing WestinTrends!

Thank you for letting WestinTrends continue to offer accessible luxury trends, inspired by everyone!

JOIN THE WESTINTRENDS COMMUNITY

Sign up here:

https://westintrends.com/welcome



OUESTIONS OR COMMENTS?

If you have questions reach out to cs@westintrends.com

FOLLOW, SHARE, & LEARN













PRODUCT REGISTRATION

https://westintrends.com/apps/product-registration




(!) CARE & MAINTENANCE

Please keep this instruction for your future reference.

- Be careful when assembling, avoid damaging the painted surface.
- Clean the lounge with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tightening screws.)
- Please do not exceed the weight limitations of this item.







CAPACITY





HARDWARE























PARTS











PARTS



PRODUCT ASSEMBLY - OVERALL VIEW


Look at following overall view of this lounge and learn the exact position of each part to be assembled.





Place Part B Lounge Base on a flat surface as below. Attach Part C Left Rear Leg to Part B Lounge Base with 2 sets of Hardware #2 Bolt, #10 Washer and #9 Nut.


Pay attention not to tighten the bolts too much. Only tighten by about 70%.



PRODUCT ASSEMBLY




Attach Part H Front Leg to Part B Lounge Base with 3 sets of Hardware #1 Bolt, #10 Washer and #9 Nut.






Attach 4 pcs of Part I Rail to Part C Left Rear Leg and Part H Front Leg with 4 pcs of Hardware #5 Screw.



PRODUCT ASSEMBLY




Do the same to attach Part D Right Rear Leg and another Part H Front Leg to Part B Lounge Base with 2 sets of Hardware #2 Bolt, #10 Washer and #9 Nut, 3 sets of Hardware #1 Bolt, #10 Washer and #9 Nut, and 4 pcs of Hardware #5 Screw.





Attach Part G Cup Holder to Part E Right Lounge Arm with 1 pc of Hardware #4 Bolt.




PRODUCT ASSEMBLY



Attach Part F Left Lounge Arm to Part C Left Rear Leg with 2 sets of Hardware #3 Bolt, #10 Washer and #9 Nut.

Attach Part E Right Lounge Arm to Part D Right Rear Leg with 2 sets of Hardware #3 Bolt, #10 Washer and #9 Nut.



7

Place Part A Lounge Backrest as below.

Attach Part A Lounge Backrest to Part C Left Rear Leg and Part D Right Rear Leg with 2 sets of Hardware #2 Bolt, #10 Washer and #9 Nut.



PRODUCT ASSEMBLY

8

Attach **Part J Wheel** to **Part D Right Rear Leg** and **Part C Left Rear Leg** with 2 sets of **Hardware #6 Bolt**, **#8 Washer** and **#7 Nut** as below.





Check and tighten all the bolts and nuts again to ensure the lounge is steady enough.

Enjoy the lounge now.



REGISTRATION & REFUND POLICY

https://westintrends.com/apps/product-registration



https://westintrends.com/policies/refund-policy



HAVING TROUBLE

• Not sure how to assemble or missing pieces?
Please contact our Customer Service Team for assistance at cs@westintrends.com

Have Order #, Part # or SKU ready to speed up customer service!

CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the HDPE furniture with a damp cloth. The material's resilience makes it resistant to most spills and stains, ensuring a hassle-free maintenance routine.

Regular cleaning not only preserves the aesthetic appeal of your furniture but also helps extend its lifespan.

Pressure washer can be used for seriously deep-cleaning - DO NOT exceed 1500 PSI - this will remove any debris and dirt.