


Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products can be requested with the 1-year warranty period. Proof of purchase must be provided. This includes the date of the purchase as well as photos of the product defect. Photos are used to determine the cause of the defect and to provide future quality control. The request will be reviewed, and replacement pieces will be sent at our discretion. For warranty information, visit <https://tiny.cc/SunnydazeWarranty>

If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at <https://tiny.cc/SunnydazeContact>

IVY CROSSWEAVE BENCH YUK-761

Review all assembly and care information before using this product. Save this manual for future reference.
Assemble components on a soft, clean surface to avoid damaging the finish.




 Inspect packaging to ensure all parts are accounted for before disposing of packing materials.
 Save the packing slip.

485
pounds
220 kg
Weight Capacity




**SCAN THIS CODE
WITH YOUR
SMARTPHONE
TO VIEW OUR
ASSEMBLY VIDEO**

No.	PARTS	QTY.
A	 Arm Panel (L/R)	2
B	 Backrest	1
C	 Seat Slat	5
D	 Side Brace	2
E	 Seat Brace	1

No.	HARDWARE	QTY.
1	 M6x30mm Bolt	14
2	 M6x20mm Bolt	2
3	 M3x15mm Screw	7
4	 Ø12 Washer	14
5	 Ø15 Washer	2
6	 Nut	16
7	 Nut Cap	4


⚠ WARNING ⚠
CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children and pets away during assembly.

TOOLS REQUIRED (not included)
 Phillips Screwdriver

ASSEMBLY

STEP 1


- A: 2
- B: 1
- 1: 4
- 4: 4
- 6: 4



Fasten Backrest (B) to Arm Panels (A) using M6x30mm Bolts (1), Washers (4), and Nuts (6).

STEP 2

- C: 5
- 1: 10
- 4: 10
- 6: 10




IMPORTANT:

Ensure the seat slat with the rounded edge is installed on the front of the unit.

Fasten Seat Slates (C) to the arm panels using M6x30mm Bolts (1), Washers (4), and Nuts (6).

STEP 3


- D: 2
- 2: 2
- 5: 2
- 6: 2



Attach Side Braces (D) to the arm panels using M6x20mm Bolts (2), Washers (5), and Nuts (6).

STEP 4

- E: 1
- 3: 7
- 7: 4



Secure the side braces to the seat using M3x15mm Screws (3).

Align Seat Brace with the center of the seat slats and secure it using five M3x15mm Screws (3).

Check all hardware to ensure it is securely fastened.

Install four Cap Nuts (7) on the back of the backrest.

Care & Maintenance

SAFE USE: For residential use only. Only use on a flat, level surface. Never stand on any part of this unit.

EXPOSURE: Over time, sunlight and weather elements may change the color of natural wood. Avoid excessive rain and high-humidity climates as wood can expand and contract with moisture changes; tighten fittings periodically. If the unit is not used for extended periods, we recommend covering or storing it indoors.

CLEAN: Use a damp cloth to clean as needed. Dry with a soft cloth. Never use harsh chemicals or abrasive materials to clean this item.

INSPECT: Periodically check hardware and tighten as necessary.

PROTECT: Always wipe up moisture promptly and dry with a soft cloth. Avoid dragging sharp or rough objects across the surface of your wood furniture. Avoid direct contact with products that may react with or can stain the wood, including, but not limited to, rubber bumper pads, glass containers, candle wax, and outdoor heating sources.

CARE & STORAGE: Protect this item from inclement weather, especially ice and snow. Move to a dry indoor location when not in use. Covering while in storage is recommended to help prevent dust build-up.

WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE APPLICATION OF CHEMICAL TREATMENTS, PROTECTIVE COATINGS, TOUCH-UP PAINT, OR CLEANING PRODUCTS.

SAFETY STATEMENTS & WARNINGS

- For residential use only. Not for commercial or industrial use.
- Ensure all fittings are tight before use. Periodically check fittings to ensure they remain tight.
- Only use this unit on a flat, level surface.
- Do not exceed the weight capacity of the furniture.
- Never stand or climb on the unit.
- Never allow children to use this product unsupervised.
- Keep furniture a safe distance from heat sources such as fire pits, patio heaters, and grills.
- Never use chemical cleaning products or polishes as doing so may damage the finish.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with assembly or the product was damaged during transit, please contact our customer service team through one of the methods mentioned at the top of page 1.

Please have the item number and order information ready to expedite response time.

WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.