

Assembly Guide




If you're having any difficulty during assembly of this product, don't hesitate to call us at 1-800-950-4782.

Our customer service experts are trained to provide step-by-step instruction and can easily replace any missing or damaged parts.

Representatives are available Monday-Friday from 8:30 a.m. to 7:30 p.m. (ET)

L-Workstation U-Workstation Return



Lot Code #

Part Number A169920D

Keep manual for future reference.

For best results, keep these tips in mind:

- ① We know you want to finish this assembly as quickly as possible, but trust us: you'll have a better experience if you take it one step at a time.
- ② Give yourself some room to work near where you want the fully assembled product.
- ③ If your floor isn't carpeted, assemble this product on the empty carton to avoid scratching.
- ④ Do you have a friend who owes you a favor? Some steps may go a little easier with a second set of hands.

DOs

- ✔ Use a #2 Phillips head screwdriver (or other handheld tools as indicated)
- ✔ Wear safety glasses at all times during assembly
- ✔ Carefully follow the instructions in this guide and complete all steps in order
- ✔ Give us a call if you're having trouble with a particularly tricky step

DON'Ts

- ✘ We know power tools are quick and easy, but you shouldn't use them when assembling this product (unless otherwise specified)
- ✘ Never move your furniture with items inside or resting on the surface
- ✘ Do not attempt to use this product before all steps have been completed

**Watch assembly videos right on your phone or computer!**



Some steps include QR codes that link to helpful videos. Watch out for the icon below! Simply open up your smartphone camera to scan the code.

(Users of older smartphones may need to install a QR Reader.)

SCAN HERE**FOR VIDEOS**

Or visit <https://bushfurniture.com/help-faq/#assembling>



WC36494C/WC36894




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Get to know your Boards

A169920D

- | | | | | | |
|---------|---|-------|------------------|---|-------|
| H146902 |  | [2] | H146905 |  | [5] |
| | Short Conn. Tube | | | Leg Leveler | |
| H146903 |  | [1] | H147237 |  | [2] |
| | Tall Conn. Tube | | | Prt. Leveler/Cap | |
| H153719 |  | [8] | WC36494C/WC36894 | | |
| | Wire Access Grommet | | | | |
| H153508 |  | [1] | H211155 |  | [3] |
| | D Panel End Cap | | | Grommet | |




Have an assembly question or need a replacement part? Just call
 1-800-950-4782, we are here to help.

Fasteners are shown actual size.

WC36494C/WC36894


H146892



[6]

KD Cam


H146893



[3]

KD Blot Double Head


H148749



[17]

M6x12mm

H148756



[4]

M6x15mm


H147242



[2]

Wood Dowel
8 x 40mm

H146895



[3]


#8x3/4"

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Hardware not to scale.

WC36494C/WC36894


H146904



[3]

Cord Management


H148745



[2]

Rt. Sup. Bracket


H148746



[2]

Lft. Sup. Bracket


H148748



[1]

Dbl. Sup. Bracket


H148747



[1]

Sng. Sup. Bracket


H146908



[1]

Wrench


H146898



[1]

Lft. Leg. Sup. Bracket

H146899



[1]

Rt. Leg. Sup. Bracket

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Hardware not to scale.

WC36494C/WC36894


H146907



[1]

Screwdriver


H27145



[1]

Glue


H153561



[3]

Spacer Nylon Silver

H146905





[2]

Leg Leveler

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

WC36496/WC36896





Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

H153719  [2]
Wire Access Grommet


H147237  [1]
Prt.Leveler/Cap


H146905  [1]
Leg Leveler

H146903  [1]
Tall Conn. Tube

H148756  [8]
M6x15mm

H153559  [1]
Round Adjsuable Lever

H153558  [1]
Round Leg Plate 5mm



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Fasteners are shown actual size.

WC36496/WC36896


H169919



[4]

#8x5/16"


H180603



[2]

#10x7/8"


H148749



[4]

M6x12mm

H148756




[4]

M6x15mm

Hardware not to scale.

WC36496/WC36896


H148746



[1]

Lft.Sup.Bracket


H148745



[1]

Rt.Sup.Bracket


H153561



[1]

Spacer Nylon Silver

H153017



[1]

Btm.Bracket


H153020



[3]

Sng.Bracket

H153016




[1]

Top.Bracket

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


WC36494C
WC36894

Go to step 3
Proceda al paso 3
Allez a l'etape 3



WC36494C
WC36894

WC36496
WC36896




Go to step 17
Proceda al paso 17
Allez a l'etape 17


Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

WC36494C
WC36894


Go to step 38
Proceda al paso 38
Allez a l'etape 38



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.



Remove bag first
Enlevez le sac en premier
Retire La bolsa primero







1 Loosen
aflojar
desserrez


2 Assemble
ensamblar
réunissez

3 Assemble
ensamblar
réunissez

4 Tighten
Apretar
serrez




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.



Remove bag first
 Enlevez le sac en premier
 Retire La bolsa primero


H153561



[1]

Spacer Nylon Silver

Open box 2
 Abra la caja 2
 Ouvrir la boîte 2







1 Loosen
 aflojar
 desserrez

2 Assemble
 ensamblar
 réunissez

3 Assemble
 ensamblar
 réunissez

4 Tighten
 Apretar
 serrez




Have an assembly question or need a replacement part? Just call
 1-800-950-4782, we are here to help.



Remove bag first
Enlevez le sac en premier
Retire La bolsa primero


Discard carton and packaging material.
Descarte el material de cartón y embalaje
Jeter le carton et le matériau d'emballage.

H153561




[1]


Spacer Nylon Silver




1 Loosen
aflojar
desserrez




2 Assemble
ensamblar
réunissez




3 Assemble
ensamblar
réunissez




4 Tighten
Apretar
serrez



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.




H153561



[1]

Spacer Nylon Silver



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


STEP 7

Install Hardware

A169920D




H148746



[2]

Lft. Sup. Bracket


H148745



[2]

Rt. Sup. Bracket


H148747



[1]







Sng. Sup. Bracket

H148748



[1]

Dbl. Sup. Bracket




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


STEP 8

Install Hardware

A169920D




H146898



[1]

Lft. Leg. Sup. Bracket


H146899



[1]



Rt. Leg. Sup. Bracket

H146905





[2]

Leg Leveler



H146899




H146898


Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Please loosen the screw first, place it just above the bracket, then tighten
Primero afloje el tornillo, colóquelo sobre el soporte, luego apriete
Veuillez desserrer la vis d'abord, la placer juste au-dessus du croisillon, puis serrer

H146907




Screwdriver



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

H146904



[3]


Cord Management

H146907




Screwdriver

H146895



[3]

#8x3/4"




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 11

Prepare Panel

A169920D


H146892



[3]

KD Cam


H146893



[3]

KD Blot Double Head


H147242




[2]

Wood Dowel
8 x 40mm


H27145





Glue



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 14


Assemble Panels

A169920D


Scan QR Code to Watch Video on:



How to Tighten KD Cams




H146892



[3]

KD Cam

H148756




[4]

M6x15mm

H146907



Screwdriver




Have an assembly question or need a replacement part? Just call 1-800-950-4782, we are here to help.


STEP 15

Install Hardware

A169920D



H148749




[17]

M6x12mm

H146907




Screwdriver



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


H146908




Wrench

[1]


Go to step 52
Proceda al paso 52
Allez a l'etape 52



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.



Remove bag first
 Enlevez le sac en premier
 Retire La bolsa primero







1 Loosen
 aflojar
 desserrez


2 Assemble
 ensamblar
 réunissez

3 Assemble
 ensamblar
 réunissez

4 Tighten
 Apretar
 serrez




Have an assembly question or need a replacement part? Just call
 1-800-950-4782, we are here to help.



Remove bag first
 Enlevez le sac en premier
 Retire La bolsa primero


H153561



[1]

Spacer Nylon Silver



Open box 2
 Abra la caja 2
 Ouvrir la boîte 2



Open box 2
 Abra la caja 2
 Ouvrir la boîte 2

- | | | | |
|--|--|--|--|
| <p>1 Loosen
aflojar
desserrez</p> | <p>2 Assemble
ensamblar
réunissez</p> | <p>3 Assemble
ensamblar
réunissez</p> | <p>4 Tighten
Apretar
serrez</p> |
|--|--|--|--|

Have an assembly question or need a replacement part? Just call
 1-800-950-4782, we are here to help.




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 20

Prepare Panel

A169920D




H169919



[4]

#8x5/16"

H153017



[1]

Btm.Bracket

H153016



[1]


Top.Bracket

H146907




Screwdriver

Open box of WC36496/WC36896
Abra la caja WC36496/WC36896
Ouvrir la boîte WC36496/WC36896




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.




Discard carton and packaging material.
 Descarte el material de cartón y embalaje.
 Jeter le carton et le matériau d'emballage.

H153561



[1]

Spacer Nylon Silver







1 Loosen
aflojar
desserrez



2 Assemble
ensamblar
réunissez

3 Assemble
ensamblar
réunissez


4 Tighten
Apretar
serrez



Have an assembly question or need a replacement part? Just call
 1-800-950-4782, we are here to help.




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.



Discard carton and packaging material.
 Descarte el material de cartón y embalaje.
 Jeter le carton et le matériau d'emballage.


Remove bag first
 Enlevez le sac en premier
 Retire La bolsa primero

H153561



[1]

Spacer Nylon Silver







1 Loosen
aflojar
desserrez


2 Assemble
ensamblar
réunissez

3 Assemble
ensamblar
réunissez


4 Tighten
Apretar
serrez



Have an assembly question or need a replacement part? Just call
 1-800-950-4782, we are here to help.




H153561



[1]

Spacer Nylon Silver




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


STEP 25

Install Hardware

A169920D




H148746



[2]

Lft. Sup. Bracket


H148745



[2]

Rt. Sup. Bracket


H148747



[1]



Sng. Sup. Bracket

H148748




[1]


Dbl. Sup. Bracket



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.




H146898



[1]

Lft. Leg. Sup. Bracket


H146899



[1]

Rt. Leg. Sup. Bracket




H146905




[2]

Leg Leveler

H146899



H146898




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Please loosen the screw first, place it just above the bracket, then tighten


Primero afloje el tornillo, colóquelo sobre el soporte, luego apriete

Veillez desserrer la vis d'abord, la placer juste au-dessus du croisillon, puis serrer

H146907




Screwdriver



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

H146904



[3]


Cord Management

H146907




Screwdriver

H146895



[3]

#8x3/4"




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 29

Prepare Panel

A169920D


H146892



[3]

KD Cam


H146893



[3]

KD Blot Double Head


H147242




[2]

Wood Dowel
8 x 40mm

H27145





Glue





Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Safety glasses
Gafas de seguridad
Lunettes de protection



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


Scan QR Code to Watch Video on:



How to Tighten KD Cams




H146892



[3]

KD Cam


H148756




[2]

M6x15mm

H146907



Screwdriver




Have an assembly question or need a replacement part? Just call 1-800-950-4782, we are here to help.


STEP 33

Install Hardware

A169920D



H148749




[17]

M6x12mm

H146907




Screwdriver




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

H146907



Screwdriver


H180603



[1]

#10x7/8"

H148756



[2]


M6x15mm

H153020





[3]


Sng. Bracket




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.




H180603



[1]


#10x7/8"

H146907



Screwdriver


H148749



[4]


M6x12mm

H148756




[4]

M6x15mm



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


H146908




Wrench

[1]


Go to step 54
Proceda al paso 54
Allez a l'etape 54



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.



Remove bag first
 Enlevez le sac en premier
 Retire La bolsa primero







1 Loosen
 aflojar
 desserrez


2 Assemble
 ensamblar
 réunissez

3 Assemble
 ensamblar
 réunissez

4 Tighten
 Apretar
 serrez




Have an assembly question or need a replacement part? Just call
 1-800-950-4782, we are here to help.



Remove bag first
 Enlevez le sac en premier
 Retire La bolsa primero


H153561



[1]

Spacer Nylon Silver

Open box 2
 Abra la caja 2
 Ouvrir la boîte 2







1 Loosen
 aflojar
 desserrez

2 Assemble
 ensamblar
 réunissez

3 Assemble
 ensamblar
 réunissez

4 Tighten
 Apretar
 serrez




Have an assembly question or need a replacement part? Just call
 1-800-950-4782, we are here to help.




Remove bag first
 Enlevez le sac en premier
 Retire La bolsa primero

Discard carton and packaging material.
 Descarte el material de cartón y embalaje
 Jeter le carton et le matériau d'emballage.




H153561




[1]

Spacer Nylon Silver


1 Loosen
 aflojar
 desserrez




2 Assemble
 ensamblar
 réunissez




3 Assemble
 ensamblar
 réunissez




4 Tighten
 Apretar
 serrez



Have an assembly question or need a replacement part? Just call
 1-800-950-4782, we are here to help.




H153561




[1]


Spacer Nylon Silver



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.




H148746



[2]

Lft. Sup. Bracket


H148745



[2]

Rt. Sup. Bracket


H148747



[1]







Sng. Sup. Bracket

H148748




[1]


Dbl. Sup. Bracket



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.




H146898



[1]

Lft. Leg. Sup. Bracket


H146899



[1]

Rt. Leg. Sup. Bracket





H146905



[2]

Leg Leveler

H146899




H146898

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


Please loosen the screw first, place it just above the bracket, then tighten
Primero afloje el tornillo, colóquelo sobre el soporte, luego apriete
Veuillez desserrer la vis d'abord, la placer juste au-dessus du croisillon, puis serrer

H146907



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


H146904



[3]


Cord Management

H146907




Screwdriver

H146895




[3]

#8x3/4"



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


H146892



[3]

KD Cam


H146893



[3]

KD Blot Double Head


H147242




[2]

Wood Dowel
8 x 40mm



H27145





Glue



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.






Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Scan QR Code to Watch Video on:




How to Tighten KD Cams



- H146892  [3]
- H148756  [4]

- H146907  Screwdriver




Have an assembly question or need a replacement part? Just call 1-800-950-4782, we are here to help.


STEP 50

Install Hardware

A169920D



H148749




[17]

M6x12mm

H146907



Screwdriver




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 51

Adjust Leg Leveler

A169920D


H146908



Wrench

[1]

Go to step 53
Proceda al paso 53
Allez a l'etape 53



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


Scan QR Code to Watch Video on:



How to Clean the Surface

Gently clean surfaces with a damp sponge eraser.

MAXIMUM WEIGHT: 100 LBS (45.3 KG)
PESO MÁXIMO: 100 LIBRAS (45.3 KILOGRAMO)
POIDS MAXIMUM: 100 LIVRES (45.3 KILOGRAMME)



MAXIMUM WEIGHT: 200 LBS (90.9 KG)
PESO MÁXIMO: 200 LIBRAS (90.9 KILOGRAMO)
POIDS MAXIMUM: 200 LIVRES (90.9 KILOGRAMME)

Congratulations! You are all done. If you have any questions or concerns, please call.

Have an assembly question or need a replacement part? Just call **1-800-950-4782**, we are here to help.


Scan QR Code to Watch Video on:



How to Clean the Surface

Gently clean surfaces with a damp sponge eraser.

MAXIMUM WEIGHT: 100 LBS (45.3 KG)
PESO MÁXIMO: 100 LIBRAS (45.3 KILOGRAMO)
POIDS MAXIMUM: 100 LIVRES (45.3 KILOGRAMME)



MAXIMUM WEIGHT: 200 LBS (90.9 KG)
PESO MÁXIMO: 200 LIBRAS (90.9 KILOGRAMO)
POIDS MAXIMUM: 200 LIVRES (90.9 KILOGRAMME)

Congratulations! You are all done. If you have any questions or concerns, please call.

Have an assembly question or need a replacement part? Just call **1-800-950-4782**, we are here to help.

Scan QR Code to
Watch Video on:




How to Clean
the Surface

Gently clean
surfaces with a damp
sponge eraser.

MAXIMUM WEIGHT: 100 LBS (45.3 KG)

PESO MÁXIMO: 100 LIBRAS (45.3 KILOGRAMO)

POIDS MAXIMUM: 100 LIVRES (45.3 KILOGRAMME)



MAXIMUM WEIGHT: 200 LBS (90.9 KG)

PESO MÁXIMO: 200 LIBRAS (90.9 KILOGRAMO)

POIDS MAXIMUM: 200 LIVRES (90.9 KILOGRAMME)

Congratulations! You are all done. If you
have any questions or concerns, please call.

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

WC36494C

A	[1]	S211143	E	[1]	S148743
B	[1]	S211144	F	[1]	S148744
C	[1]	S211145	G	[2]	H150931
D	[1]	S211146			

WC36894

A	[1]	S211149	E	[1]	S175260
B	[1]	S211150	F	[1]	S175261
C	[1]	S211151	G	[2]	H150931
D	[1]	S211152			

WC36496

H [1] S153013

I [1] S180826

J [1] S158609

WC36896

H [1] S175265

I [1] S180827

J [1] S158609

WARRANTY INFORMATION/INFORMATIONS POUR LA GARANTIE/INFORMACIÓN DE GARANTÍA

BUSH BUSINESS FURNITURE'S WRITTEN WARRANTY TO YOU

In order to provide you with timely assistance, please thoroughly inspect your furniture for missing or defective parts immediately after opening the carton. To receive replacement or missing parts under this warranty, call our Consumer Service Department TOLL-FREE at 1-800-950-4782. Please have the Model, Part, and Lot Numbers found in the instruction manual available for your reference. You will also need your sales receipt or other proof of purchase. Replacement part(s) will be shipped to you at no charge with Bush Industries assuming all shipping and handling charges.

This Bush Business Furniture product is warranted to the original purchaser at the time of purchase and for a period of ten years thereafter.

We warrant to you, the original purchaser, that our furniture and all its parts and components are free of defects in material or workmanship. "Defects," as used in this warranty, is defined as any imperfection which impairs the use of the furniture product.

Our warranty is expressly limited to the replacement of furniture parts and components. Except for the limitations listed below, for ten years after the date of purchase, Bush will replace parts that are defective in material or workmanship.

Limitations involving materials and components: The materials and components listed below are covered according to the following schedule from the date of sale:

- Five Years – Glides, casters, polymer-based components, panel, upholstery fabrics, foam, laminates, veneer finishes, and other covering materials.
- One Year – Metal mechanism and related components in manual height adjustable products.

This warranty applies under conditions of normal use. Our Bush Business Furniture products are not intended for outdoor use. This warranty does not cover: 1) defects caused by improper assembly or disassembly; 2) defects occurring after purchase due to product modification, intentional damage, accident, misuse, abuse, negligence or exposure to the elements; and 3) labor or assembly costs. 4) batteries are not included.

IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY, SHALL NOT EXTEND BEYOND THE DURATION OF THE WRITTEN WARRANTY STATED ABOVE, AND IN NO EVENT SHALL BUSH BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM USE OF THE PRODUCT. Some states do not allow a limitation on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation and exclusion may not apply to you.

This warranty gives you specific legal rights. You may also have other rights that may vary from state to state.

VOTRE GARANTIE BUSH BUSINESS FURNITURE

Afin de vous assister rapidement, veuillez inspecter votre mobilier en détail immédiatement après l'ouverture du carton en cas de pièces manquantes ou défectueuses. Pour recevoir une pièce de rechange ou manquante couverte par cette garantie, appelez notre département de service clientèle GRATUITEMENT au 1-800-950-4782. Veuillez tenir à disposition les numéros de modèle, de pièce et de lot qui se trouvent dans le manuel d'instruction pour votre référence. Vous aurez également besoin de votre reçu ou d'une autre preuve d'achat. La (les) pièce(s) de rechange vous sera (seront) envoyée(s) sans frais, Bush Industries se chargeant de tous les frais d'expédition.

Tout le produit Bush Business Furniture est garanti à l'acheteur original à partir de la date d'achat pour une période d'e dix ans. Nous vous garantissons, à vous l'acheteur original, que notre mobilier et toutes ses pièces et composants sont sans défaut de matériau ou de fabrication. Le terme "défauts" utilisé dans cette garantie, est défini comme étant toutes les imperfections qui compromettent l'utilisation du meuble.

Notre garantie est expressément limitée au remplacement des pièces et des composants du mobilier. Sauf les limitations énumérées ci-dessous, pendant dix ans après la date d'achat, Bush remplacera toute pièce défectueuse dans le matériau ou sa fabrication.

Limitations impliquant des matériaux et des composants: Les matériaux et composants énumérés ci-dessous sont couverts conformément au calendrier suivant à compter de la date de vente:

- Cinq ans - Glissements, roulettes, composants à base de polymères, panneaux, tissus d'ameublement, mousse, stratifiés, finitions de placage et autres matériaux de revêtement.
- Un an - Mécanisme métallique et composants associés dans des produits à réglage manuel de la hauteur.

Cette garantie d'applique sous des conditions d'utilisation normale. Nos produits ne sont pas destinés à être utilisés en plein air. Cette garantie ne couvre pas: 1) les défauts causés par un mauvais assemblage ou démontage, 2) les défauts ayant lieu après l'achat et dus à la modification du produit, des dommages intentionnels, des accidents, une mauvaise utilisation, un mauvais traitement, la négligence ou l'exposition aux éléments, et 3) les frais de main d'œuvre ou d'assemblage. 4) les piles ne sont pas incluses.

LES GARANTIES TACITES, Y COMPRIS LA GARANTIE DE QUALITE MARCHANDE, NE S'ETENDRONT PAS AU-DELA DE LA DUREE ECRITE CITEE CI-DESSUS, ET BUSH NE SERA EN AUCUN CAS RESPONSABLE DES DOMMAGES ACCESSOIRES OU INDIRECTS RESULTANT DE L'UTILISATION DU PRODUIT. Certains états ne permettent pas d'appliquer une limite à la durée de la garantie tacite, ni une exclusion ou limitation des dommages accessoires ou indirects; dans ce cas les limitations ou exclusion ci-dessus peuvent ne pas s'appliquer à vous.

Cette garantie vous donne des droits légaux spécifiques. Il se peut que vous ayez également d'autres droits qui peuvent varier d'un état à l'autre.

GARANTIA ESCRITA DE BUSH BUSINESS FURNITURE PARA USTED

Para brindarle asistencia oportuna, por favor, verifique detalladamente que a su mueble no le falte o tenga piezas defectuosas inmediatamente después de abrir la caja. Para recibir un reemplazo o la parte faltante bajo esta garantía, llame a nuestro Departamento de Servicio al Consumidor GRATIS al 1-800-950-4782. Sírvase traer los números de modelo, parte y lote que se encuentran en el manual de instrucciones disponible para su referencia. Además, necesitará el recibo de su compra u otra prueba de compra. La(s) pieza(s) de reemplazo le será(n) enviada(s) sin recargo por Bush Industries asumiendo los gastos de envío y manipuleo.

Todo mueble de Bush Business Furniture es garantizado al comprador original al momento de la compra y por un periodo de diez años en adelante.

Le garantizamos a usted, el comprador original, que nuestros muebles sus partes y componentes están libres de defectos en materiales o trabajo. "Defectos", según se usa en esta garantía, se define como una imperfección que perjudica el uso del producto mobiliario.

Nuestra garantía se limita expresamente al reemplazo de partes y componentes mobiliarios. Excepto las limitaciones enumeradas a continuación, durante diez años después de la fecha de compra, Bush reemplazará cualquier parte defectuosa en material o trabajo.

Limitaciones que involucran materiales y componentes: Los materiales y componentes que se enumeran a continuación están cubiertos de acuerdo con el siguiente calendario a partir de la fecha de venta:

- Cinco años: deslizadores, ruedas, componentes a base de polímeros, paneles, telas de tapicería, espuma, laminados, acabados de enchapado y otros materiales de recubrimiento.
- Un año: mecanismo de metal y componentes relacionados en productos de altura manual.

Esta garantía se aplica bajo condiciones de uso normal. Nuestros productos de Bush Business Furniture no son para uso en exteriores. Esta garantía no cubre: 1) defectos causados por un ensamblaje o desensamblaje inadecuado; 2) defectos que ocurren después de la compra debido a modificación del producto, daño intencional, accidente, mal uso, abuso, negligencia o exposición a los elementos; y 3) costos de trabajo o ensamblaje. 4) las baterías no están incluidas.

LAS GARANTÍAS IMPLICADAS, INCLUYENDO LA GARANTÍA DE COMERCIABILIDAD, NO SE EXTENDERÁN MÁS ALLÁ DE LA DURACIÓN DE LA GARANTÍA ESCRITA MENCIONADA, Y EN NINGÚN CASO BUSH SERÁ RESPONSABLE POR DAÑOS INCIDENTALES O CONSIGUIENTES COMO RESULTADO DEL USO DEL PRODUCTO. Algunos estados no permiten una limitación sobre el tiempo de duración de la garantía implicada o la exclusión o limitación de daños incidentales o consiguientes, de manera que la limitación y exclusión mencionadas pueden no aplicarse para usted.

Esta garantía le otorga derechos legales específicos. Puede también tener otros derechos que pueden variar según los estados.

10-Year
Manufacturer's
Warranty

Register your product online:

Scan the QR Code or go to
[https://bushfurniture.com/
activate-warranty/](https://bushfurniture.com/activate-warranty/)



Assembly tips & how to videos:

Scan the QR Code to access our video
guides [https://bushfurniture.com/
help-faq/#assembling](https://bushfurniture.com/help-faq/#assembling)

