
ASSEMBLY AND INSTALLATION INSTRUCTIONS

T0780

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements.

2. Read and save these instructions.



Installation Steps

Turn off the power at fuse or circuit box

- 1. Unscrew the two bolt nuts (D), remove the two rubber pads (E) and mounting plate unit (A) from the fixture.
- 2. Attach the mounting plate unit (A) to the outlet box by using two mounting screws (B).
- 3. Pull out the source wires from the outlet box. Make wire connections using wire connectors (C) as follows:
 - Connect the hot wire (black insulation) from the fixture to the black wire from the power source.
 - Connect the neutral wire (white insulation) from the fixture to the white wire from the power source.
 - Attach the fixture ground wire (bare wire) to the mounting plate unit (A) with the green ground screw, then depending on local code, connect it to the house ground wire with the wire connector (C).

Carefully put all of the wires back into the outlet box.


- 4. Attach the canopy of the fixture to the mounting plate unit (A) by aligning and inserting the two fixture mounting screws into the open holes on the canopy, then secure it with the two rubber pads (E) and two bolt nuts (D).
- 5. Install the bulb (not included). See relamping label at socket area or packaging for maximum wattage allowed.
- 6. Attach the glass shade to the metal cover of the fixture by aligning studs and slots, then rotate it carefully until it is locked in place. Then attach the two metal wires to the inside shade of the fixture by inserting ends of wires into four studs on the shade.


Outlet Box House Ground Wire Green Ground Screw Mounting Plate Unit (A) Fixture Mounting Screw Mounting Screw (B) Fixture Ground Wire Wire Connector (C) Canopy Rubber Pad (E) Bolt Nut (D) Metal Cover **Fixture** Max. 60W Type A Bulb (not included) Glass Shade Metal Wire

Turn off the power at fuse or circuit box



The following parts are available for reorder if damaged or missing.





1 Year Warranty

Vaxcel warrants all of our products against defects in workmanship and finishes for one year following the date of shipment.

Exclusions: This warranty does not include the failure of products from extreme acts of nature; environmental conditions not suited for the products intended use; operation in temperatures outside of the range specified in the instruction manual; usage with improper power supply, power surges or dips. For coastal locations, some corrosion is considered normal for the environment.

Vaxcel reserves the right to repair, replace or issue a credit for any properly installed product, provided it is returned per RMA instruction. This warranty is limited to the cost of the product only and does not extend to transportation, installation or replacement costs.

How can warranty service be obtained? info@vaxcel.com 1-800-482-9235

