
Freestanding Vanity INSTALLATION INSTRUCTIONS









PRIOR TO INSTALLATION:

- Inspect product to ensure no damages have occurred while in shipping.
- Observe all plumbing and building codes in accordance with your state and local requirements.
- · Floor must be level prior to installation of vanity.
- All dimensions are nominal! Be sure to measure your vanity prior to installation.
- The step-by-step guidelines in the installation instructions are a general reference. Should there be any discrepancies, Swiss Madison cannot be held liable. It is recommended to install all Swiss Madison products by hiring a licensed professional.
- Read installation and maintenance instructions thoroughly before installing. Be sure to use proper tools and always wear proper personal safety accessories for your protection.

If you have any questions or concerns please contact us: 1-434-623-4766 info@swissmadison.com

SUGGESTED TOOLS & MATERIALS:

INCLUDED PARTS:



Safety Glasses

Silicone






Drop Cloth








Vanity Base







Vanity Sink


Hardware


FREESTANDING VANITY

INSTALLATION INSTRUCTIONS



- 1. Top bars (2) 2. Rear bottom bar 3. Right side panel 4. Left side panel Left side panel
 Base panel
 Legs (2)
 Right side door
 Left side door
- A. Cam bolt
- B. Cam lock
- C. Wooden dowel
- D. Screws
- E. Hinges
- F. Foam pads






1. Prepare Frame


- Insert 1 wooden dowel (C) into each side of the top bar (1) as shown. Repeat to second top bar (1).
- · Insert 4 wooden dowels (C) into dowel holes on the rear bottom bar (2) as shown.
- Insert 2 wooden dowels (C) into the side of the right side panel (3) as shown. Screw 6 cam bolts

(A) into the right side panel (3) into the designated cam bolt holes. Repeat to the left side panel (4).



2. Assemble Frame


- \cdot Use 2 cam locks (B) to connect a top bar (1) to the left side panel (4) as shown. Using an additional 2 cam locks (B) attach the remaining top bar (1) to the left side panel (4).
- \cdot Use 2 cam locks (B) to attach the rear bottom bar (2) to the left side panel (4) as shown.
- \cdot Repeat all steps to the right side panel (3).



- 3 -


3. Construct Base


- \cdot Align base panel (5) with bottom of cabinet frame as shown.
- \cdot Screw 6 screws (D) through the base panel (5) and into the frame as shown.



4. Attach Legs

- · Insert 2 wooden dowels (C) into each leg set (6) as shown.
- \cdot Place a foam pad (F) onto the bottom of the legs sets (6) according to the diagram below.
- \cdot Attach each leg set (6) to the cabinet base (5) as shown.
- Finish securing the legs sets (6) into place by using 4 screws (D).






D

6

 \bigcirc


5. Attach Hinges

- \cdot Remove threaded caps from bottom of screws in a hinge (E).
- Align caps in designated holes of the right side door (7). Using a mallet, hammer caps into the holes, making sure that each cap is open at the top.
- \cdot Align hinge with the right side door (7) as shown. Then, screw the hinge (E) into the threaded caps until tight. Repeat the above process with an additional hinge (E).
- Once the above steps are completed to the right side door panel (7), repeat them all to the left side door panel (8).



6. Attach Doors


- \cdot Using 2 screws per hinge (E), connect the right door panel (7) to the cabinet body as shown.
- \cdot Repeat this step to attach the left door panel (8) to the cabinet body.



5


7. Optional: Secure Vanity to Wall

Hardware not included



8. Vanity Top Installation

- Install faucet and drain according to manufacturer's installation instructions. Do not overtighten, this may cause the sink to crack.
- \cdot Set the vanity top on top of the vanity base, checking the location of the p-trap and drain.
- Remove vanity top from vanity base. Apply a thin bead of silicone around the vanity base and set the vanity top carefully in place.
- · Remove excess silicone with a wet cloth.



6



ONE YEAR LIMITED WARRANTY

Swiss Madison® products are made with quality materials and excellent craftsmanship to provide our customers with beautiful, durable, long-lasting products. Should there be any defects in materials or craftsmanship under regular use that are discovered within the first year of installation, Swiss Madison® will provide replacement parts at no charge, or at its discretion, replace any product or part of the product that is deemed defective, under normal installation, use, service or maintenance. This warranty applies only to the original purchaser. Proof of purchase will be required in the instance of a claim.

Swiss Madison® recommends all installations of Swiss Madison® products to be conducted by a licensed, professional plumber or contractor. Swiss Madison® will not be held responsible for any damage or product failure due to improper installation, misuse, or failure to utilize a licensed professional for installation. Swiss Madison® is not responsible for any installation or removal costs.

This One Year Limited Warranty Will Be Voided If:

- The installation recommendations were not followed by the installer
- The product has been moved from its initial place of installation
- The product has in any way been modified from its packaged state
- The product has been subjected to improper maintenance, abuse, misuse, excessive use of chemicals, accidents, or other damages, etc.

Swiss Madison® makes no implication that its products comply with any local building or plumbing codes. It is the consumer's responsibility and obligation to determine local code compliance prior to and during installation. This warranty extends only to the original purchaser and first consumer.

Swiss Madison® is not responsible for any special, incidental or consequential damages associated with the installation, replacement, return or use of the original purchaser's product. This includes, but is not limited to: freight costs, labor, travel time, lost profit, home damages and other contingent liabilities and costs (including, without limitation, costs associated with 'professionals' or 'experts', investigations, audits, analyses, attorneys and any other professional/hired services).

The Swiss Madison® warranty is a comprehensive and explicit limit of liability. All items not disclosed within the warranty are not addressable within the responsibility of Swiss Madison®. Certain states have variances regarding implied warranties; in those situations, we remain fully compliant.

If you have any questions or concerns, please contact us directly at 1-434-MADISON (623-4766)

WARNING: Contents of your order may contain sharp and possibly other harmful pieces and may cause hazard to children and adults. Swiss Madison® is not responsible in any way for personal damages.