



DESIGNED IN CALIFORNIA



— 23.5" OUTDOOR METAL DINING TABLE —

THANK YOU!

We appreciate you for choosing WestinTrends!

Thank you for letting WestinTrends continue to offer accessible luxury trends, inspired by everyone!

JOIN THE WESTINTRENDS COMMUNITY

Sign up here:

[***https://westintrends.com/welcome***](https://westintrends.com/welcome)



QUESTIONS OR COMMENTS?

If you have questions reach out to
[**cs@westintrends.com**](mailto:cs@westintrends.com)

FOLLOW, SHARE, & LEARN



PRODUCT REGISTRATION

[***https://westintrends.com/apps/product-registration***](https://westintrends.com/apps/product-registration)



ACCESSIBILITY - COMMUNITY - VALUE - SUSTAINABILITY

! CARE & MAINTENANCE

Do not overtighten screws. (Insert all screws before tightening screws.)

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and nuts before use.
- Inspect and tighten all bolts on a regular basis to ensure proper performance and safety.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- We recommend the use of furniture covers to protect when not in use, and store in a dry and protective area during off season.

TOOLS REQUIRED



ALLEN WRENCH
(PROVIDED)



TABLE
180 LBS
CAPACITY



1 PERSON
ASSEMBLY



UP TO 15 MIN.
ASSEMBLY

HARDWARE

1

BOLT
M6 x 10mm



4 PCS

2

WASHER
M6



4 PCS

3

BOLT
M8 x 30mm



6 PCS

4

WASHER
M8



6 PCS

PARTS

A

SUPPORT POST



1 PC

B


CONNECT DISC



1 PC

C

TABLE TOP



1 PC

D


BASE



1 PC

PRODUCT ASSEMBLY - OVERALL VIEW


Look at following overall view of this table and learn the exact position of each part to be assembled.



PRODUCT ASSEMBLY

1


Place **Part A Support Post** straight up as shown below. Attach **Part B Connect Disc** to **Part A Support Post** with 3 sets of **Hardware #3 Bolt** and **#4 Washer M8**.



2


Place **Part C Table Top** on flat surface with four assembly holes upward. Attach the assembled **Part A Support Post+ Part B Connect Disc** to **Part C Table Top** with 4 sets of **Hardware #1 Bolt and #2 Washer (M6)**.

Pay attention to protect the paint.



3

Attach **Part D Base** to **Part A Support Post** with 3 sets of **Hardware #3 Bolt and #4 Washer (M8)**.



4

Check and tighten all the bolts again to ensure the table is steady enough.

Enjoy the table now.



REGISTRATION & REFUND POLICY

[*https://westintrends.com/apps/product-registration*](https://westintrends.com/apps/product-registration)



[*https://westintrends.com/policies/refund-policy*](https://westintrends.com/policies/refund-policy)



HAVING TROUBLE

- **Not sure how to assemble or missing pieces?**

Please contact our Customer Service Team for assistance at [*cs@westintrends.com*](mailto:cs@westintrends.com)

Have Order #, Part # or SKU ready to speed up customer service!

CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap, rinse thoroughly and dry in the sun. Avoid harsh cleansers or polish and do not use bleach or acid on the metal product.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture but also helps extend its lifespan.