

Parts Included:

1 Top Assembly

4 Legs

24 Bolts 3/16 x 1/2"

Tools Required: Philips Screwdriver



It is strongly recommended that this table be assembled by TWO PERSONS to avoid marking or scratching the finish. It is easier to assemble this product upside down.

- Locate and unpack all of the parts required and place them on a soft surface (i. e. carpet).
- 2. Place the Top assembly upside down on a soft surface.
- Match numbers on base to numbers on top.
- Attach Leg Assembly and Middle Assembly to legs using 3/16 x 1/2 Bolts as shown. Leave loose.
- 5. Attach Leg Assembly to Top Assembly using 3/16 x 1/2 Bolts as shown. Tighten loose.
- Turn the completed table upright.

It is recommended that you periodically check and tighten all parts during the lifetime of the product.

Clean with a damp cloth and buff dry with a soft cloth. Use of commercial polishes or waxes is not recommended. Use coasters under beverages and articles that may scratch. Do not place hot items directly on the surface.

