

DORSEY ROUND DINING TABLE

ASSEMBLY INSTRUCTIONS




PARTS PACKING CONFIGURATIONS

BOX#1

A. TABLE TOP


1 PC







BOX#2

B. TABLE BASE

1 PC




FULLY ASSEMBLED



HARDWARE KIT PACKED IN BOX #1

NO.	DESCRIPTION	IMAGE	QTY
1	ALLEN BOLT (5/16"x35mm) with SPRING WASHER (5/16") and FLAT WASHER (5/16")		8 SETS
2	ALLEN KEY		1 PC



STEP 1



DORSEY ROUND DINING TABLE ASSEMBLY INSTRUCTIONS



STEP 2



ASSEMBLY COMPLETE

PAGE 2 OF 2