



CART/TROLLEY FOR STREET VENDOR POPCORN MACHINES




CONTENTS



DO NOT TIGHTEN SCREWS UNTIL FULLY ASSEMBLED


1 ATTACH SIDE PANELS

- Attach the **side panels** to the **top shelf** and **bottom shelf** with **screws**.
- Continue to secure the **side panels** with additional **screws** from the back.



2 ATTACH FRONT PANEL


- Attach the **front panel** to the cart with **screws**.



DO NOT TIGHTEN SCREWS UNTIL FULLY ASSEMBLED


3 ATTACH LEGS

- Flip the cart upside down.
- Slide the **long legs** through the **bottom shelf** on the **side panel** with handle holes and align holes with side panel.
- Slide the **short legs** through the **bottom shelf** and align holes with side panel.
- Secure with **long screws** and **nuts**.




4 ATTACH WHEELS

- Slide the **axle** through the **short legs**.
- Attach the **wheels** onto the **axle**.
- Secure with **axle pins**.



5 ATTACH SIDE SHELF AND HANDLE

- Attach the **handle** to the **side panel** and secure with **screws** and **nuts**.
- Slide the **side shelf** onto the opposite side of the cart.



6 FINAL CHECK

- Stand the pedestal upright on a level surface/floor.
- Ensure wheels and long legs are touching the floor evenly.
- Firmly tighten all screws to ensure they are secure.

7 SECURE THE POPCORN MACHINE

- Place the popcorn machine on top of the cart.
- Open the popcorn machine and remove the drop door and clean out tray.
- Locate the holes on the bottom of the popcorn machine and secure to the cart with **bolts** and **wing nuts**.

