

Thank you for purchasing Leick Furniture products. Contact customer service for comments or concerns.

Sheboygan, WI

920-451-4060

info@leickfurnituresince1910.com

www.leickfurnituresince1910.com

Assembly Instructions, #10933 Sofa Table



Part A: Top Assembly

Part B: (4) Legs

Part C: Base Assembly

Part D: (12) Bolts

- Part E: (12) Lock Washers
- Part F: (12) Flat Washers
- Part G: Allen Wrench

- 1. Place table top assembly upside down and fasten the legs with (8) bolts, flat washers and lock washers using the Allen wrench. The lock washer goes between the head of the bolt and the flat washer. Do not tighten yet.
- 2. Fasten the base assembly to the legs with (4) bolts, flat washers and lock washers, tighten bolts. Note: there is no slate tile on the back side of the top assembly, make sure you orient the slate toward the front with the drawer fronts. Hint: if you are by yourself, lay the table on its back; it is easier to not have to hold the base up while inserting bolts. Now you can tighten the bolts in step 1.
- 3. You did it! Begin to enjoy your new Leick Furniture.