
INSTRUCTION MANUAL



Outdoor Adirondack Coffee Table SKU: OP8010

(!) CARE & MAINTENANCE

Please keep this instruction for your future reference.

- Be careful when assembly, avoid hurting the table top surface.
- · Clean the table with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- * Do not overtighten screws. (Insert all screws before tighten screws.)
- · Please do not exceed the weight limitations of this item.













UP TO 20 MIN. ASSEMBLY

HARDWARE











PARTS








PRODUCT ASSEMBLY



Place Part A Table Top upside down on soft surface like carpet to avoid damage to the paint.

Attach 4 pcs of part C Table Legs to Table Top with 4 sets of hardware 2 Bolt and hardware 3 Nut.

Do not tighten bolts too much at this stage.



PRODUCT ASSEMBLY



Tighten all the bolts again to ensure the steady of this table.

Place the table to normal position as below and finish the assembly.

