

### NU6917

# LAGUNA 24-IN STEEL CAULDRON FIRE PIT

Assembly Instructions





# Questions, problems, missing parts?

Before returning to your retailer, call our Consumer Hotline at 1-800-759-0977, Monday – Friday, 8 a.m. – 5 p.m. (CST).

# **THANK YOU!**

Thank you for purchasing this product! We work around the clock and around the globe to ensure that our products maintain the highest possible quality. However, in the rare case of issues during assembly or use of this product, please contact our Consumer Hotline at 1-800-759-0977 for immediate assistance before contacting your retailer. Please read the warranty information at the back of this User Manual for further details.

# SAFETY INFORMATION

Please read and follow ALL instructions before assembling or using this product, particularly the safety statements. Failure to follow instructions and warnings could result in damage to property, serious injury or death



- For outdoor use only.
- If using on wood deck, set the firepit on top of a fireproof base/pad.
- Use in well ventilated area away from flammable liquids and materials.
- Do not leave firepit unattended.
- Do not touch while in use
- Keep children and pets a safe distance from the firepit.








# **INSTALLATION AND ASSEMBLY**

# **PARTS LIST**

| ITEM | PART<br>DESCRIPTION | PART<br>NUMBER | PART<br>QTY |
|------|---------------------|----------------|-------------|
| Α    | Fire Bowl           | NUP4365        | 1           |
| В    | Stand Legs          | NUP4366        | 4           |
| С    | Small Ring          | NUP4367        | 1           |
| D    | Large Ring          | NUP4368        | 1           |
| E    | Spark Screen        | NUP4369        | 1           |
| F    | Poker               | NUP4370        | 1           |
| G    | Bolt (M6)           | NUP4371*       | 8           |
| н    | Bolt (M8)           |                | 3           |



<sup>\*</sup> Items included in Hardware Pack, NUP4371 Carefully unpack all parts. Inspect for missing or damage parts.

# **ASSEMBLY**

#### STEP 1:

Align hole in the Large Ring with hole in the Stand Leg, insert Bolt (M6) through the holes and securely fasten bolt with a screwdriver. Do not over-tighten bolts.





#### STEP 2:

Follow Step 1 above to assemble the rest of the Stand Legs.



# **INSTALLATION AND ASSEMBLY**

# **ASSEMBLY**

#### STEP 3:

Align the holes of the Small Ring with the holes of Stand Leg, insert Bolts (M6) through each hole and securely fasten bolt with a screwdriver. Do not over-tighten bolts.





#### STEP 4:


Follow Step 3 above to assemble the rest of the Stand Legs.





#### STEP 5:

Insert Bolts (M8) in the top wall of Fire Bowl and tighten. Place Fire Bowl into the holder.





#### STEP 6:

Place Spark Screen on the Fire Bowl.



# **PRODUCT WARRANTY**

#### 1-YEAR LIMITED WARRANTY

This product is warranted to the original purchaser to be free from defects in material or workmanship for a period of one (1) year from the date of the original retail purchase.

This warranty does not cover defects or damage due to improper installation, alteration, accident, or any other event beyond the control of the manufacturer. Defects or damage resulting from misuse, abuse, or negligence will void this warranty. This warranty does not cover scratching or damage that may result from normal usage.

This product is not intended for institutional or commercial use; the manufacturer does not assume any liability for such use. Institutional or commercial use will void this warranty.

This warranty is nontransferable and is expressly limited to the repair or replacement of the defective product. During the warranty period, the manufacturer shall repair or replace defective parts at no cost to the purchaser. Shipping charges and insurance are not covered and are the responsibility of the purchaser. Labor charges and related expenses for removal, installation, or replacement of the product or components are not covered under this warranty.

The manufacturer reserves the right to make substitutions to warranty claims if parts are unavailable or obsolete.

The manufacturer shall not be liable for loss of use of the product or other consequential or incidental costs, expenses, or damages incurred by the consumer for any other use. The user assumes all risk of injury resulting from the use of this product.

This warranty is expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use to the extent permitted by federal or state law. Neither the manufacturer nor any of its representatives assume any other liability in connection with this product.

All warranty claims must be made through the retailer where the product was originally purchased. A purchase receipt or other proof of date of purchase will be required to process all warranty claims. The model number and part numbers found within the assembly instructions will be required when submitting any part requests or warranty claims.

For further warranty information or inquiries, please call 1-800-759-0977 or email warranty@splashnetxpress.com



Blue Wave Products, Inc. 1745 Wallace Avenue, Suite B Saint Charles, IL 60174