



DGR20P3S

Item No.	Description	Part code	Qty per unit
1	Backsplash assembly	G20F08-011500Z assm	1
2	Oven/Broil injector base	G20A01-021100	2
3	Nozzle 1.3	G20A01-021213	1
4	Grill burner aluminum pipe	G20C01-023300	1
5	Oven burner aluminum pipe	G20C01-023100	1
6	Bottom cup mounting plate	G20C01-024200	2
7	Mid burner cover	G20A01-040102	2
7	Mid burner	G20A01-040101	2
7	Mid burner cup	G20A01-040100	2
8	Spark plug-for top burner 900mm	G20A01-170405	1
9	Large burner cover	G20A01-040202	1
9	Large burner	G20A01-040201	1
9	Large burner cup	G20A01-040200	1
10	Spark plug-for top burner 680mm	G20A01-170404	1
11	Small burner cover	G20A01-040002	1
11	Small burner	G20A01-040001	1
11	Small burner cup	G20A01-040000	1
12	Spark plug-for top burner 1050mm	G20A01-170406	2
13	Cast iron grate left	G20F08-021400	1
13	Cast iron grate right	G20F08-021500	1
14	Cook top plate	G20F08-020100	1
15	Aluminum pipe-L/B	G24F08-022300	1
16	Aluminum pipe-L/F	G24F08-022400	1
17	Aluminum pipe-R/B	G24F08-022600	1
18	Aluminum pipe-R/F	G24F08-022500	1
19	Main gas pipe	G20F08-030700	1
20	Thermostat	G20C02-030617	1
21	Safety valve 0.5	G20D02-030523	1
22	Safety valve 0.81	G20D02-030530	2
23	Safety valve 0.95	G20D02-030531	1
24	Control panel	G20F08-030300	1
25	Knob	G20A07-030100	5
26	Digital timer with LED lights	G20F08-190300	1
27	Knob ring	G20A07-030200-00	5
28	Digital timer support	G24F08-191000	1
29	Side plate	G20C01-071002	2
*	Complete door assembly	GC0103-100400Z	1
30	Internal fixation plate	G20C01-102500	4
31	Door inside glass	G20F08-100500	2
32	Door inner seal bar	G20C01-103100	1
33	Door inner seal ring	G20C01-103000	1
34	Oven door frame	G20C01-100600	1

Item No.	Description	Part code	Qty per unit
35	Window fixing piece for door	G20C01-102600	4
36	Door body strengthening part	G20C01-101000	2
37	Door hinge	G20C01-110000	2
38	Door glass wool	G20C01-103500	1
39	Door inside window	G20F08-101100	1
40	Outer door glass	GC0103-100400	1
41	Handle	G20B03-101900	2
42	Door handle strut	G20C01-100300	2
43	Door glass bracket	G20A10-100900	2
44	Door stainless steel trim	G20F08-102000	1
*	Drawer assembly	G20F08-120100Z	1
46	Drawer outside plate	G20F08-120100	1
47	Drawer inside plate	G20C02-120200-04	1
48	Drawer plate	G20F08-120500-02	1
49	Drawer slid rail	G24F08-120700	2
50	Front plate	G20C01-070102	1
51	Front plate Beam	G20A01-070200	1
53	baffle	G20C01-111100	2
54	Foot	G20C01-071500	4
55	Cavity right plate	G20A01-070500	1
56	Oven burner fire board	G20A01-080900	1
57	Oven burner pipe	G20B01-080100	1
58	Spark plug-for oven burner 230mm	G20C01-170502	1
59	Anti-tip bracket	G20A01-212500	1
60	Leg installation plate	G20A01-071100	2
61	Drawer heat insulation board	G20C01-072100	1
62	Bottom tray (with hole)	G20A01-070700	1
63	Rack	G20C01-071900	2
64	Broil tray	G20C01-215000	1
65	Broil grill	G20C01-215100	1
66	Broil burner pipe	G20C01-090100	1
67	Broil burner fire board	G20C01-090300	1
67	Broil burner infrared radiation net	G20C01-090500	1
68	Spark plug-for grill burner 540mm	G20C01-170500	1
69	Thermocouple	G20C01-072400	1
70	Cavity top plate	G20C01-070601	1
73	Weight block	G20A01-210200	1
74	Fixed plate	G20C01-034500	2
75	Power cord	G20A07-160105	1
76	Power cord fixed part	G20A01-160200	1
77	Ignition	G20C01-170106	1
78	Cavity left plate	G20A01-070400	1
79	Back plate	G20C01-070301	1

Item No.	Description	Part code	Qty per unit
80	Oven lamp	G20C01-180101	1
81	Cavity back glass wool	G20C01-072900	1
83	Baffle plate	G20C01-072000	1
84	Rear connecting plate	G20C01-022000	2
85	Diversion plate	G20C01-075000	1
86	Regulator	G20C01-034001	1
87	Regulator adapter	G24G02-034200	1
88	Glass wool	G20A01-070800	1
90	Control panel rubber mat	G20F08-120900	1
91	Control panel barrier strip	G20F08-214500	1
92	Control panel glass wool	G20F08-036000	1
94	Regulator support	G24G02-034500	1
*	Front plate seal bar	G20G02-071200	1
*	Cooktop thermocouple 300mm	G20A01-030900	2
*	Cooktop thermocouple 500mm	G20A01-030901	2
*	Cavity ring	G20F08-071200	1