

40 MM CARTRIDGE

Installation Instructions:

1. Turn off water supply. Remove lever handle and escutcheon assemblies.
2. Carefully remove cartridge wiggling back and forth until cartridge comes out of the valve.
3. Reassembly with new cartridge.

NOTE: To adjust temperature limit stop, turn valve to desired hottest temperature, remove temperature limit stop turn clockwise and reinstall so that the white protrusion on cartridge is touching the red protrusion on the temperature limit stop.

CARTUCHO DE 40 MM

Instrucciones de Instalación:

1. Cierre el suministro de agua. Retire los ensambles de palanca y placa decorativa.
2. Retirar con cuidado el cartucho moviendo hacia atrás y adelante hasta que salga el cartucho de la válvula. 3. Volver a montar con un nuevo cartucho.

NOTA: para ajustar la temperatura, girar la válvula a la temperatura más caliente deseada, retire el límite de temperatura y gire hacia la derecha y volver a instalar de manera que la protuberancia blanca en cartucho está en contacto con la protuberancia roja en el tope de límite de temperatura.

