



POLY GARDON 48" BACKLOSS BONCH

THANK YOU!

We appreciate you for choosing WestinTrends!

Thank you for letting WestinTrends continue to offer accessible luxury trends, inspired by everyone!

JOIN THE WESTINTRENDS COMMUNITY

Sign up here:

https://westintrends.com/welcome



OUESTIONS OR COMMENTS?

If you have questions reach out to cs@westintrends.com

FOLLOW, SHARE, & LEARN













PRODUCT REGISTRATION


https://westintrends.com/apps/product-registration




(!) CARE & MAINTENANCE


Do not overtighten screws. (Insert all screws before tightening screws.)


- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.




PARTS







PARTS






PRODUCT ASSEMBLY



Attach Part D Bench Rail to Part B Left Bench Leg and Part C Right Bench Leg with 2 PCS of Hardware #1 Bolt.


Do the same to another Bench Rail and the other two Legs.

Do not tighten bolts too much at this stage.




2

Attach another combined legs (Part B+C+D) to Part A Bench Top with 4 PCS of Hardware #2 Bolt, Hardware #4 Washer and Hardware #5 Nut.



3


Attach another combined legs (Part B+C+D) to Part A Bench Top with 4 PCS of Hardware #2 Bolt, Hardware #4 Washer and Hardware #5 Nut.



PRODUCT ASSEMBLY




Fix 4 PCS of **Part E Wooden Corners** to the combined legs (**Part B+C+D**) and the rail of **Part A Bench Top** with 8 PCS of **Hardware #3 Screw** as below.





Tighten all the bolts and nuts again for your secure usage. Avoid overtightening, as doing so can cause damage to the product.

Thanks for purchasing this bench, enjoy it.



REGISTRATION & REFUND POLICY

https://westintrends.com/apps/product-registration



https://westintrends.com/policies/refund-policy



HAVING TROUBLE

Not sure how to assemble or missing pieces?
Please contact our Customer Service Team for assistance at cs@westintrends.com

Have Order #, Part # or SKU ready to speed up customer service!

CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the HDPE furniture with a damp cloth. The material's resilience makes it resistant to most spills and stains, ensuring a hassle-free maintenance routine.

Regular cleaning not only preserves the aesthetic appeal of your furniture but also helps extend its lifespan.

Pressure washer can be used for seriously deep-cleaning - DO NOT exceed 1500 PSI - this will remove any debris and dirt.