


Console Sink

INSTALLATION INSTRUCTIONS





PRIOR TO INSTALLATION:

- Inspect product to ensure no damages have occurred while in shipping.
- Observe all plumbing and building codes in accordance with your state and local requirements.
- Floor must be level prior to installation.
- Console height is not adjustable.
- All dimensions are nominal! Be sure to measure your sink prior to installation.
- The step-by-step guidelines in the installation instructions are a general reference. Should there be any discrepancies, Swiss Madison cannot be held liable. It is recommended to install all Swiss Madison products by hiring a licensed professional.
- Read installation and maintenance instructions thoroughly before installing. Be sure to use proper tools and always wear proper personal safety accessories for your protection.


QUESTIONS OR CONCERNS?

Please contact us:


1-434-623-4766

info@swissmadison.com

INCLUDED PARTS:



Vessel Sink &
Legs Set



Bolts


SUGGESTED TOOLS & MATERIALS:



Safety Glasses




Gloves



Adhesive




Drop Cloth



Level

PARTS FOR REFERENCE:

- A. Legs (4)
- B. Cross Bracket (1)
- C. Round Bracket (1)
- D. Adjustable Rubber Feet (4)
- E. Small Allen Wrench (1)
- F. Large Allen Wrench (1)
- G. Screws for Round Bracket (4)
- H. Locking Nuts for Cross Bracket (4)

**1 Assemble Frame**


- Stand first leg (A) upside down and attach cross bracket (B) to the top horizontal bar, with the screw opening facing up (towards you).
- Stand the second leg (A) upside down and attach cross bracket (B) to the top horizontal bar, with the screw openings facing up (towards you). Repeat this for the final two legs so that all four legs are attached to the cross bracket.
- Begin securing the legs to the cross bracket. Using the smaller Allen wrench (E), attach the locking nuts (H) to each opening on the cross bracket until fully secure.

NOTE: Tighten using a quarter-turn at a time to avoid damage to the legs or bracket.

- With the frame upside down, attach the round bracket (C) to all four horizontal bars on the opposite ends of the legs using screws (G).

NOTE: The inside of the round bracket should be facing up (towards you). Do not fully tighten any screw until all four screws (G) are loosely attached to each leg.


- Add the adjustable rubber feet (D) to the openings on each leg. Once the frame is secure, flip the frame and adjust the feet as needed until level.



2 Attach Sink

- Place the vessel sink on the top of the frame. Make sure the drain hole is aligned with the round bracket (C).
- Gently lift the sides of the basin to apply a small line of adhesive on to each bar of the frame.

NOTE: The basin will be fully stable after you attach your plumbing to the sink drain.



Console Sink

USE & CARE INSTRUCTIONS

SINK CARE AND MAINTENANCE

- Use water at a temperature between 32 °F and 140 °F to clean the sink. Directly poured boiled water may cause the ceramic body to crack.
- If there are stains left on the sink, rinse it immediately with clean water and wipe it with a clean cloth to prevent sink from damage.
- Prevent hard projects from directly impacting the surfaces of the product.
- Do not clean the ceramic products with steel brush or a scouring pad and the like, which may damage the ceramic surfaces.
- Do not use drastic or corrosive detergents to clean the sink, which may damage the surfaces of ceramic body.
- Use neutral detergents to clean sink once a week at least.

CONSOLE LEGS CARE AND MAINTENANCE

- The surface hardness is relatively high, but it can still be scratched by sharp objects. In daily use, try to avoid using steel wool balls, sharp knives, etc. To vigorously scratch its surface, so as not to damage the protective film on the surface and affect its aesthetics and corrosion resistance.
- Be careful when placing items to prevent other metal items or hard items from colliding and rubbing against stainless steel products.
- Avoid allowing stainless steel products to come into long-term contact with corrosive substances such as acids, alkali, and salts. If accidentally in contact, rinse thoroughly with clean water in a timely manner and dry it.



RUB LIGHTLY
WITH SOFT CLOTH



CLEAN
PERIODICALLY



CLEAN SINK WITH
MILD ABRASIVE



HARSH
CLEANERS



STEEL
WOOL



LEAVING BLEACH
ON FOR TOO LONG

ONE-YEAR LIMITED WARRANTY

Swiss Madison® products are made with quality materials and excellent craftsmanship to provide our customers with beautiful, durable, long-lasting products. Should there be any defects in materials or craftsmanship under regular use that are discovered within the first year after delivery, Swiss Madison® will provide replacement parts at no charge, or at its discretion, replace any product or part of the product that is deemed defective, under normal installation, use, service or maintenance. This warranty applies only to the original purchaser. Proof of purchase must be submitted with any warranty claim.

Swiss Madison® recommends that all installations of Swiss Madison® products to be conducted by a licensed plumber or contractor. Swiss Madison® will not be held responsible for any damage or product failure due to improper installation, misuse, or failure to utilize a licensed plumber or contractor for installation. Swiss Madison® is not responsible for any installation or removal costs.

THIS ONE-YEAR LIMITED WARRANTY WILL BE VOIDED IF:

- The installation instructions were not followed by the installer
- The product has been moved from its initial place of installation
- The product has in any way been modified from its original condition
- The product has been subjected to improper maintenance, abuse, misuse, excessive use of chemicals, accidents, or other damages

Swiss Madison® makes no warranty that its products comply with any local building or plumbing codes. It is the consumer's responsibility and obligation to determine local code compliance prior to and during installation.

Swiss Madison® is not responsible for any special, incidental or consequential damages associated with the installation, replacement, return or use of the original purchaser's product. This includes, but is not limited to: freight costs, labor, travel time, lost profit, home damages and other contingent liabilities and costs (including, without limitation, costs associated with 'professionals' or 'experts', investigations, audits, analyses, attorneys and any other professional/hired services). Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

The Swiss Madison® warranty is a comprehensive and explicit limit of liability. All other warranties are hereby disclaimed and waived.

QUESTIONS OR CONCERNS? Please contact us directly at: 1-434-MADISON (623-4766)



WARNING:

Contents of your order may contain sharp and possibly other harmful pieces and may cause hazard to children and adults. Swiss Madison® is not responsible in any way for personal injuries or damages.