


Pantry

IMPORTANT

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.




Part List




A.
Top
1 pc.




D.
Shelf
2 pcs.



E.
Rail
2 pcs.



B.
Side Panel
1 pc.




C.
Side Panel
1 pc.




F.
Upright
1 pc.



G.
Back Panel
2 pcs.



H.
Door
1 pc.



I.
Door
1 pc.

For assembly see instructions in carton 20 05103 0692.