



FINISH® POWERBALL® MAX IN 1™

Dishwasher Detergent Tablets

Finish® Max in 1™ Shine and Protect™ gives you the brilliant clean and shine you expect, plus added protection against Glass Corrosion, so your glasses keep their sparkling shine for longer and are protected wash after wash. Max in 1™ is available in a re-sealable bag and there is no need to unwrap individual tablets.

Features & Benefits

- World's #1 Recommended Brand* (*Recommended by more dishwasher brands worldwide)
- No need to pre-soak or pre-rinse with Powerball® as it cuts through grease & scrubs away burnt & dried-on food.
- Finish® Powerball® Tabs are 3X concentrated cleaning power of regular Finish® powder
- Removes tough stains like tea & coffee
- Prevents redeposits & provides glass protection.
- Easy-to-use, wrapper free & pre-measured dishwasher capsules.





FINISH® POWERBALL® MAX IN 1™

Dishwasher Detergent Tablets

Use Instructions

- Insert detergent tab into dishwasher.
- Run wash cycle.

Technical data	FINISH® POWERBALL® MAX IN 1™
Color/Form	White & Blue, Solid
pH	9.8
Shelf Life	4 Years

Product	Pack size	Dilution	Product code	
FINISH® POWERBALL® MAX IN 1™	4 x 50 count	Ready-to-use	CB932679	🇨🇦
FINISH® POWERBALL® MAX IN 1™	3 x 74 count	Ready-to-use	CB932693	🇨🇦
FINISH® POWERBALL® MAX IN 1™	3 x 90 count	Ready-to-use	CB956286	🇨🇦

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate.

FINISH® POWERBALL® MAX IN 1™ is a registered trademark of Reckitt Benckiser and is used with their permission.

www.diversey.com

© 2019 Diversey, Inc. All Rights Reserved. PSS90745 (19/122)