

# USER'S MANUAL

WTR20

UNIVERSAL WIRELESS VIDEO TRANSMITTER AND RECEIVER

**BOSS**<sup>®</sup>  
AUDIO SYSTEMS

BOSS Audio Systems

3451 Lunar Court • Oxnard, CA 93030

[www.bosssaudio.com](http://www.bosssaudio.com) | 805.322.8794

tech support: [www.bosssaudio.com/support/technical-support](http://www.bosssaudio.com/support/technical-support)



0316

# USER'S MANUAL

WTR20

UNIVERSAL WIRELESS VIDEO TRANSMITTER  
AND RECEIVER



**DO NOT FULLY RELY ON REVERSE CAMERA  
WHEN BACKING UP.**

**ALWAYS CHECK YOUR SURROUNDINGS  
BEFORE BACKING UP.**

**BOSS**<sup>®</sup>  
AUDIO SYSTEMS

# Thank you for choosing Boss Audio

Please read the user's manual carefully before installation and use

## Before Installation

- This product is only intended to be used and installed in +12 VDC, negative ground electrical systems.
- Before attempting to install any of the components, plan the location, placement and wiring.
- Before drilling or securing any components, double check for gas lines, brake lines, gas tank, moving parts, or any other vital vehicle part.
- When making electrical connections, it's recommended they be soldered and protected w/heat shrink or electrical tape

## Wireless TX/RX Specifications

Operating Frequency: 2.4-2.483 GHz

TX Distance: 35 ft. (11 m) max

Power Input TX: 12 VDC, 110 mA


Power Output TX: 12 VDC, 60 mA

Power Input RX: 12 VDC, 60 mA

Video System Support: NTSC/PAL


Operating Temperature: -50° F to +140° F

## Wireless Transmitter



Video Signal from Camera  
12 V Output to Camera

## Wireless Receiver



Video Signal to Mirror  
12 V Input

## Tech Support

If you questions regarding the installation or products, please call us

M-F 8:30a-5p PST

805-322-8794

[www.bossaudio.com](http://www.bossaudio.com)