

OUTDOOR ROUND BAR TABLE

THANK YOU!

We appreciate you for choosing WestinTrends!

Thank you for letting WestinTrends continue to offer accessible luxury trends, inspired by everyone!

JOIN THE WESTINTRENDS COMMUNITY

Sign up here:

https://westintrends.com/welcome



OUESTIONS OR COMMENTS?

If you have questions reach out to cs@westintrends.com

FOLLOW, SHARE, & LEARN













PRODUCT REGISTRATION

https://westintrends.com/apps/product-registration



(!) NOTICE

Do not overtighten screws. (Insert all screws before tightening screws.)


- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws, and nuts before use.
- Inspect and tighten all bolts on a regular basis to ensure proper performance and safety.
- Do not use or store this item in the proximity of open flame or flammable/ combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- We recommend the use of furniture covers to protect when not in use, and store in a dry ano
 protective area during off season.



HARDWARE




PARTS



PRODUCT ASSEMBLY - OVERALL VIEW

Look at following overall view of this table and learn the exact position of each part to be assembled.




PRODUCT ASSEMBLY



If you want to use the table as a coffee table, please skip this step and follow step 2.

To use as a bar table, connect **Part C Screw Rod** to **Part D Nether Central Tube** and make sure it is fully tightened.


Insert Part E Upper Central Tube to Part D Nether Central Tube.





Attach **Part F Connect Disc** to the assembled central tube. To use as a coffee table, please attach **Part F Connect Disc** directly to **Part D Nether Central Tube**. Use one set of **Hardware #1 Bolt and #4 Washer (M10)** at this step.

Make sure to loosely attach the bolt first, then turn **Part F Connect Disc** until its holes fit the tube. Then fully tighten the bolt.




3

Place Part A Table Top on flat surface with the four assembly holes facing upward.

Attach the assembled parts to **Part A Table Top** with 4 sets of **Hardware #3 Bolt** and **#5 Washer (M6)**. Fully tighten the bolts at this step.

Be careful to protect the coating.




PRODUCT ASSEMBLY



Attach Part B Base to Part C Nether Central Tube with Hardware #2 Flat Bolt and make sure it is fully tightened.


Felt pads are provided on the bottom of the base for floor protection.





Turn the table upwards. Make sure all bolts are tightened and the table is steady.

Enjoy the table now.



REGISTRATION & REFUND POLICY

https://westintrends.com/apps/product-registration



https://westintrends.com/policies/refund-policy



HAVING TROUBLE

• Not sure how to assemble or missing pieces?
Please contact our Customer Service Team for assistance at cs@westintrends.com

Have Order #, Part # or SKU ready to speed up customer service!

CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture but also helps extend its lifespan.