



# HOME DRIVING RANGE KIT

## GETTING STARTED



Thank you for choosing the SKLZ Home Driving Range Kit. We are dedicated to providing you with the best tools and instruction possible to help you prepare for your sport. If there is anything else we can do to help, don't hesitate to send us an email at [help@4implus.com](mailto:help@4implus.com) or give us a call toll-free **800-729-5954**.

### BEFORE YOU BEGIN:

- Read all instructions carefully before using. Failure to do so may result in injury or damage to the product.
- Always check for wear and tear before use. If any is found, do not use the product.
- If you are missing any of the Home Driving Range Kit components, please contact Implus customer service toll free at **800-729-5954**.
- Adult assembly required.

### ⚠️WARNING:

**PHYSICIANS WARNING:** Not all exercise equipment and programs are suitable for everyone. It is recommended that you consult your physician before using this equipment or beginning this or any other exercise program.

**CHOKING HAZARD:** Contains small balls. Not for children under 3 years of age.

- Home Driving Range Kit is under tension when assembled. Please take the utmost care when releasing the tension during disassembly. Failure to do so may result in injury. (nets, goals, anything with resistance cables)
- To avoid pinching, use caution when assembling the push-button tubing.
- Regularly check for wear and tear. Stop using Home Driving Range Kit if any part of it breaks. Failure to do so could result in injury.
- When in use, make sure the Home Driving Range Kit is set up in a clear area to avoid injury.
- When using the Home Driving Range Kit, others should stay clear of the area to reduce the risk of injury.
- Any alteration of this product or its components will result in a disclaimer of liability.

### ⚠️CAUTION:

- Keep away from fire and heat sources.
- Do not leave Home Driving Range Kit outdoors for extended periods of time.
- When done, disassemble Home Driving Range Kit and store after use. Do not leave Home Driving Range Kit outdoors.
- When in use, make sure the Home Driving Range Kit is set up in a clear area to avoid damage to property.

### 1-YEAR LIMITED WARRANTY

This warranty does not cover damages resulting from accident, misuse, abuse or lost merchandise, and is only valid in the USA. Need proof of purchase for warranty coverage. **Questions? Email [help@4implus.com](mailto:help@4implus.com) or call toll-free 800-729-5954.**


Made in China. ©2019 Implus Footcare, LLC. Manufactured and distributed by Implus Footcare, LLC: 2001 T.W. Alexander Drive, Box 13925, Durham, NC 27709-3925. SKLZ is a trademark or registered trademark of Implus Footcare, LLC in the U.S. and/or other countries. Product features, appearance and specifications may be subject to change without notice. Unauthorized duplication is a violation of applicable local and international laws.

## IN THE BOX




## GETTING STARTED


### PRACTICE NET SETUP



1. Fit each segment on the fiberglass rod (B) into the next until the rod is fully extended. Repeat with other rod.
2. Lay the net (A) out flat and folded on itself so that both SKLZ logos face up.
3. Insert one of the rods (B) into the net (A) sleeve from the corner. It is easiest if you start on the bottom sleeve. Gently feed the rod through the sleeve. Do not pull the rod from the other side. Make sure both ends of the rod are sticking out of each side of the net sleeve and bend the rod to easily smooth out the sleeve.



4. Insert the second rod (B) into the top sleeve of the net (A) following the same directions in step #3.
5. Add the L-Joint connector piece (D) to the bottom rod (B) with the connector knob facing down. Slide the connector and rod into the pocket grommet and repeat on the other side.



6. Insert the top rod (B) into the open end of one of the L-Joints (D). This will bring the net to a standing position. Repeat on the other side.
7. For more stability, drive the three stakes (C) through the two free grommets in the front and the third grommet at the back of the net.

### LAUNCH PAD SETUP

#### TEE USE:

Depending on the club, insert either tee used into the Launch Pad hole through the bottom of the mat.

#### CLUB USE RECOMMENDATIONS:

**DRIVER:** Use tall tee on the fairway

**FAIRWAY WOOD | HYBRID CLUBS | IRONS**

1. Use short tee or

2. On the fairway or rough without tee

**WEDGES:** Use on the fairway or rough without tee

