





UNIVERSAL WALL PLATE DIMENSIONS AND DISPENSER HOLE-PATTERN GUIDE

Use the dispenser hole-pattern guide to ensure that the backplate fits the dispensing platform.


 Potential location for inserting screw fastener




ACCENT




ADX-7™




ADX-12™




CS2




CS4




CS6 & CS8




ES4, ES6 & ES8




FMX-12™




FMX-20™




LTX-7™




LTX-12™



NXT® 1000 mL



NXT 2000 mL



TFX™



GOJO Industries, Inc.
One GOJO Plaza, Suite 500
P.O. Box 991 • Akron, OH 44309-0991
Tel: 1-330-255-6000 • Toll-free: 1-800-321-9647
Fax: 1-800-FAX-GOJO