



MAIN COMPONENTS

1. Peeling blade
2. Blade for coring and spiral slicing
3. Adjustment screw for peeling blade
4. Wing nut
5. Prong
6. Wing nut for peeling blade
7. Holder for peeling blade
8. Locking arm
9. Axle
10. Handle
11. Handle for suction cup
12. Base (with suction cup)

SAFETY & CARE

- **NOTICE:** the blade and prongs are sharp!
- Wash the apple peeler with mild dish soap in hot water before first use.
- NOT DISHWASHER SAFE

ASSEMBLY

1. Press the locking arm (8) to release the axle, and pull the handle (10) and axle (9) fully out.
2. Unscrew the handle (10) from the axle (9) and turn it clockwise. Screw it on again as pictured.

OPERATION

1. Place the suction cup base (12) on a level surface and secure by pressing the handle (11) down.
2. Place the stalk-end of an apple on the prongs (5) and turn the handle (10) to push the apple toward the peeling blade (1).
3. The apple will be peeled by the blade, sliced in a spiral and the core will be removed.

OPERATION (continued)

4. Remove the peeled apple.
5. Press the locking arm (8) and pull the handle (10) and axle (9) out. Remove the core from the prongs (5).
6. Wash the apple peeler with mild dish soap in hot water and dry thoroughly.

ADJUSTMENTS

- To center blade for coring and spiral slicing, loosen the wing nut (6). Release the locking arm (8) and push the axle (9) forward until the prongs (5) go through the ring blade to the core. Hold the blade for coring and spiral slicing (2) firmly and retighten the wing nut (6).
- To adjust minimum apple diameter, use a flathead screwdriver on adjustment screw (3) until the desired distance is achieved.
- To adjust peel thickness, loosen wing nut (6), adjust the peeling blade (1) to the desired peel thickness and retighten wing nut (6).