

» Screwwriter to remove battery cover.
 » 6 C batteries required (if not using AC Adaptor)

TOOLS NEEDED:

» Do not allow dirt or moisture to get into the Lightning Bolt. Store indoors when not in use.
 » Only operate the Lightning Strike on level surfaces.
 » Do not power Lightning Bolt on without balls in the loader. This can damage the Lightning Bolt.
 » Do not put hands or fingers inside the Lightning Bolt with the power cord plugged in or batteries in the unit.
 » Make sure all persons and pets are clear of the Lightning Bolt and the path of the ball before powering on.
 » Anyone hitting balls must wear a NOCSAE approved batting helmet.

CAUTION:

» To avoid electrical injury, adults should always be present during use.
 » Only use Bolt Balls with the Lightning Bolt machine. Failure to do so may result in a damaged machine.
 » Always operate under adult supervision.
 » Only use Lightning Bolt Balls with the Lightning Bolt. Failure to do so may result in a damaged machine.
 » Do not put hands or fingers inside the Lightning Bolt with the power cord plugged in or batteries in the unit.
 » Make sure all persons and pets are clear of the Lightning Bolt and the path of the ball before powering on.
 » Anyone hitting balls must wear a NOCSAE approved batting helmet.

WARNING:


» Ensure your practice area is clear and no people, animals or objects are in the path of the ball.
 » Read all setup and usage instructions carefully.
 » Make sure you have all of the Lightning Bolt components.

BEFORE YOU BEGIN:

Thank you for choosing SKLZ Lightning Bolt. We are dedicated to providing you with the best tools and instruction possible to help you unleash your athletic potential. If there is anything else we can do to help you optimize your training, don't hesitate to send us an email (customerservice@sklz.com) or give us a call (1-877-225-7275).

INSTRUCTION MANUAL

- INCLUDES:**
- » Lightning Bolt
 - » Bolt Balls (12)
 - » AC Adaptor



IDEA SUBMISSION

If you have an idea for a new and innovative sports training product, visit SKLZ.com to submit your concept. Some restrictions may apply.

LIMITED WARRANTY

REGISTER YOUR PRODUCT AT SKLZ.COM TO ENSURE WARRANTY COVERAGE, GET NEW PRODUCT INFORMATION AND SPECIAL DEALS FROM SKLZ

Pro Performance Sports (PPS) / SKLZ warrants to the original consumer purchaser of any PPS/SKLZ product it manufactures that the product will be free of defects in materials or workmanship for 90 days (unless specified in alternate warranties) from the date of purchase. If defective and purchased from a retail store, return the product along with receipt to the retail store where the product was purchased. If the item was purchased from PPS/SKLZ, return the product along with the packing slip (proof of purchase) postage prepaid to the address below for replacement consideration. Label: Attn: Returns

This warranty does not cover damages resulting from accident, misuse, abuse or lost merchandise. Only valid in the USA. All returns sent to PPS/SKLZ require a Return Merchandise Authorization number (RMA). For returns to PPS/SKLZ and for all other Customer Service inquiries, please email customerservice@sklz.com or call toll free, 1-877-225-7275 for a return authorization number for any exchange.

Made in Taiwan. ©2013 Pro Performance Sports, LLC. All rights reserved. Manufactured and distributed by SKLZ/Pro Performance Sports: 2081 Faraday Avenue, Carlsbad, CA 92008 U.S.A. SKLZ, SKLZ Pro Grade, SKLZ Chrome and Sport-Brella are registered trademarks of Pro Performance Sports, LLC, its subsidiaries and affiliates. Product features, appearance, and specifications may be subject to change without notice. Unauthorized duplication is a violation of applicable local and international laws.

SKLZ

LIGHTNING BOLT




SKLZ.COM



Training Videos & Articles: SKLZ.com
[facebook.com/SKLZbaseball](https://www.facebook.com/SKLZbaseball)
twitter.com/SKLZ

LIGHTNING BOLT ASSEMBLY



STEP 1 ASSEMBLE LIGHTNING BOLT CRICKET


NOTE: If an electrical outlet is not available, using a screwdriver, unscrew the battery cover from the bottom of the Lightning Bolt Base and add 6 C batteries. Replace the battery cover.

1. Connect the Base Connector to one Feeder Tube.
2. Connect the remaining tubes with the Tube Connectors. Fill with Bolt Balls and add Tube Cap. Insert the assembled Ball Feeder into the Base.
3. If using AC Adapter, remove from box and insert black connector into the back of the Lightning Bolt. Plug in to the nearest outlet.

STEP 2 ADJUST LIGHTNING BOLT

1. Use the Pitching Height Adjustment Knob to adjust the Lightning Bolt to the desired trajectory. Turn the adjustment knob clockwise to lower the ball trajectory. Turn counter clockwise to heighten the trajectory.
2. Turn on machine and begin training.

NOTE: If ball trajectory needs to be changed, turn off the Lightning Bolt before making any adjustments.



COLLECT BOLT BALLS

1. Remove the Ball Feeder from the Base.
2. Place the Ball Feeder (arrow pointing down) over the ball and push down. Repeat until the feeder is full.
3. Reconnect the Ball Feeder to the Lightning Bolt and begin training.