

ASSEMBLY INSTRUCTION









This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

Attach Under Stretcher (C) and Upper Stretcher (B) to Side Frame (A) by Bolt (H) and Allen Wrench (M) as shown.




Attach Stretcher (D) to Side Frame (A) by Bolt (I) and Allen Wrench (M) as shown.




Attach Side Panel (E) and Side Panel (F) to Under Stretcher (C) and Upper Stretcher (B) by Screw (J) as shown.

*Please notice the direction of side panels.




4

Attach the other Side Panel (E) and Side Panel (F) to Under Stretcher (C) and Upper Stretcher (B) by Screw (J) as shown.



Turn the unit upright. Cover the bolt head by Bolt Cover (L). Attach Glass Pad (K) to Side Frame (A), then place Glass Top (G) as shown.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.