

QUANTITY

1

1


4

QUANTITY

1

BOX 1 - HEADBOARD-FOOTBOARD				BOX 2 - SIDERAILS			
PART NO.	IMAGE	DESCRIPTION	QUANTITY	PART NO.	IMAGE	DESCRIPTION	QUAN
A		HEADBOARD PANEL	1	н		LEFT SIDERAIL	1
				l I		RIGHT SIDERAIL	1
В		LEFT HEADBOARD WING	1	J		CENTER SLAT	1
С		RIGHT HEADBOARD WING	1	К		LEG SUPPORT	
D		HEADBOARD DRAWER BOX	2	BOX 3 - SLAT ROLL			
				PART NO.	IMAGE	DESCRIPTION	QUAN
E		FOOTBOARD	1	L		SLAT ROLL	1
F		CORNER SUPPORT	2				
G	Ů	CORNER LEG SUPPORT	2	YOUR BOX MAY CONTAIN			
HARDWARE KIT PACKED IN BOX 1				EXTRA HARDWARE			
1		ALLEN BOLT (6X50mm)	4				
2		ALLEN BOLT (6X65mm)	6				
3		FLAT HEAD BOLT (6X15mm)	16	NOT PROVIDED			
4	00	METAL PLATE	4	ASSEMBLE ON A SOFT SURFACE			
5		PHILLIPS HEAD BOLT (8X20mm)	8	FULLY ASSEMBLED			
6	0	SPRING WASHER (M8)	8				
7	0	FLAT WASHER (M8)	8				
8	a market	WOOD SCREW (8X30mm)	9				

15







10

ALLEN BOLT (6X40mm)


ALLEN KEY




















STEP 11:























STEP 14:








STEP 16:












STEP 18:




STEP 19:



STEP 20:



STEP 21:



INSTRUCTIONS FOR ADJUSTING LEVELER:

Position the bed in your space and locate the leveler under each leg support (\mathbf{K}) .

Turn the leveler counter-clockwise to extend the leveler and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.

UPDATED: JULY 7TH, 2023

MAINTENANCE INSTRUCTIONS:

- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

