


Daybed




IMPORTANT

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.


Part List




O1.
Drawer Front
2 pcs.




O2.
Drawer Back
2 pcs.



E.
Side Panel
2 pcs.



O5.
Drawer Bottom
2 pcs.



O6.
Support
4 pcs.

For assembly see instructions in carton 20 05525 0851.

Home Styles Customer Service: www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319