


WWT
WESTINTRENDS

DESIGNED IN CALIFORNIA



KIDS OUTDOOR POLY ROCKING
CHAIR WITH SIDE TABLE 3-PIECE SET

THANK YOU!

We appreciate you for choosing WestinTrends!

Thank you for letting WestinTrends continue to offer accessible luxury trends, inspired by everyone!

JOIN THE WESTINTRENDS COMMUNITY

Sign up here:

[*https://westintrends.com/welcome*](https://westintrends.com/welcome)



QUESTIONS OR COMMENTS?

If you have questions reach out to
cs@westintrends.com

FOLLOW, SHARE, & LEARN



PRODUCT REGISTRATION

[*https://westintrends.com/apps/product-registration*](https://westintrends.com/apps/product-registration)




ACCESSIBILITY - COMMUNITY - VALUE - SUSTAINABILITY

TABLE OF CONTENTS

ASSEMBLY INSTRUCTIONS

Kids Outdoor Poly Rocking Chair 4

Kids Outdoor Poly Adirondack Side Table 11



— KIDS OUTDOOR POLY ROCKING CHAIR —

! CARE & MAINTENANCE

Please keep these instructions for your future reference.

- Be careful when assembling, avoid damaging the painted surface.
- Clean the chair with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tightening screws.)
- Please do not exceed the weight limitations of this item.

TOOLS REQUIRED



CHAIR
300 LBS
CAPACITY



1 PERSON
ASSEMBLY



UP TO 20 MIN.
ASSEMBLY

HARDWARE

1

SCREW
M6 x 80mm



4 PCS

2

SCREW
M6 x 70mm



2 PCS

3

SCREW
M6 x 45mm



6 PCS

4

SCREW
M4 x 18mm



4 PCS

5

SCREW
M4 x 35mm



4 PCS

6

STEEL PLATE



2 PCS

PARTS

A


CHAIR SEAT



1 PC

B


CHAIR BACKREST



1 PC

C

RIGHT REAR LEG




1 PC

PARTS

D


LEFT REAR LEG



1 PC

E


RIGHT ARM



1 PC

F

LEFT ARM



1 PC

G

RIGHT FRONT LEG



1 PC

H

LEFT FRONT LEG



1 PC

I


ROCKING BASE



2 PCS

PRODUCT ASSEMBLY - OVERALL VIEW

Look at following overall view of this chair and learn the exact position of each part to be assembled.




PRODUCT ASSEMBLY

1

Attach **Hardware #6 Steel Plate** to **Part G Right Front Leg** with 2 pcs of **Hardware #5 Screw**.

Do the same to attach another **Hardware #6 Steel Plate** to **Part H Left Front Leg** with 2 pcs of **Hardware #5 Screw**.




2

Attach **Part G Right Front Leg** to **Part E Right Arm** with 2 pcs of **Hardware #4 Screw**.

Attach **Part H Left Front Leg** to **Part F Left Arm** with 2 pcs of **Hardware #4 Screw**.

Pay attention that the angled edge of the leg is facing towards the end of the arm.



PRODUCT ASSEMBLY

3


Insert the tenon on the end of **Part E Right Arm** to the mortise in **Part C Right Rear Leg** and attach with 1 pc of **Hardware #2 Screw**.

Do the same to attach **Part F Left Arm** to **Part D Left Rear Leg**.



4

Attach the combined **Part (C+E+G)** and **Part (D+F+H)** to **Part I Rocking Base** with 4 pcs of **Hardware #1 Screw**.




PRODUCT ASSEMBLY

5


Attach **Part B Chair Backrest** to **Part C Right Rear Leg** with 1 pc of **Hardware #3 Screw**.

Attach **Part A Chair Seat** to **Part C Right Rear Leg** and **Part G Right Front Leg** with 2 pcs of **Hardware #3 Screw**.



6


Attach the left frame (**Part D+F+H+I**) to the assembled part with 3 pcs of **Hardware #3 Screw**.



7


Check and tighten all the screws again to ensure the chair is steady enough.

Enjoy the chair now.





DESIGNED IN CALIFORNIA



KIDS OUTDOOR POLY ADIRONDACK
SIDE TABLE

! CARE & MAINTENANCE

Please keep these instructions for your future reference.

- Be careful when assembling to avoid damaging the top surface.
- Clean the table with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use. Do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tightening screws.)
- Please do not exceed the weight limitations of this item.

TOOLS REQUIRED



TABLE
50 LBS
CAPACITY



HARDWARE

1

SCREW
M6 x 55mm




12 PCS

PARTS

A


TABLE TOP
WITH APRON



1 PC

B


TABLE LEG



4 PCS

C


RAIL I



2 PCS

C


RAIL II



2 PCS

PRODUCT ASSEMBLY - OVERALL VIEW

Look at the overall view of this table and learn the exact position of each part to be assembled.




PRODUCT ASSEMBLY

1

Insert **Part C Rail I** into the mortise of **Part B Table Legs** and secure it with 1 pc of **Hardware #1 Screw**.

Do not tighten screws too much at this stage.




PRODUCT ASSEMBLY

2


Attach another **Part B Table Legs** to **Part C Rail I** with 1 pc of **Hardware #1 Screw**.

Do the same to attach another set of Part B and Part C.




3

Loosely attach the combined Part B and Part C to the aprons of **Part A Table Top** with 2 pcs of **Hardware #1 Screw**.




4

Attach the other combined Part B and Part C to the aprons of Part A Table Top with 2 pcs of Hardware #1 Screw.




5

Place the other 2 pcs of Part D Rail II between Part B Table Legs and attach them with 4 pcs of Hardware #1 Screw.



6

Tighten all the screws. Turn over the table and enjoy it now.



REGISTRATION & REFUND POLICY

<https://westintrends.com/apps/product-registration>



<https://westintrends.com/policies/refund-policy>



HAVING TROUBLE

- **Not sure how to assemble or missing pieces?**

Please contact our Customer Service Team for assistance at cs@westintrends.com

Have Order #, Part # or SKU ready to speed up customer service!

CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the HDPE furniture with a damp cloth. The material's resilience makes it resistant to most spills and stains, ensuring a hassle-free maintenance routine.

Regular cleaning not only preserves the aesthetic appeal of your furniture but also helps extend its lifespan.

Pressure washer can be used for seriously deep-cleaning - **DO NOT exceed 1500 PSI** - this will remove any debris and dirt.