


WWT
WESTINTRENDS
WWT

DESIGNED IN CALIFORNIA



POLY 54" PORCH SWING WITH
FOLDING CUP HOLDER

THANK YOU!

We appreciate you for choosing WestinTrends!

Thank you for letting WestinTrends continue to offer accessible luxury trends, inspired by everyone!

JOIN THE WESTINTRENDS COMMUNITY

Sign up here:

[*https://westintrends.com/welcome*](https://westintrends.com/welcome)



QUESTIONS OR COMMENTS?

If you have questions reach out to
cs@westintrends.com

FOLLOW, SHARE, & LEARN



PRODUCT REGISTRATION

[*https://westintrends.com/apps/product-registration*](https://westintrends.com/apps/product-registration)



! NOTICE

Do not overtighten screws. (Insert all screws before tightening screws.)

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws, and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable / combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Please adjust the speed slowly when you use electric drill for assembling to avoid screw slipping.

NO TOOLS REQUIRED




TABLE
600LBS
CAPACITY



2 PERSON
ASSEMBLY



UP TO 20 MIN.
ASSEMBLY

HARDWARE

| | | | | |
|--|---|------------------------------------|-------------------------------------|--|
| 1 BOLT M6 x 55mm 2 PCS | 2 BOLT M6 x 60mm 16 PCS | 3 M6 NUT 18 PCS | 4 M6 WASHER 18 PCS | 5 EYE HOOK M8 x 35mm 2 PCS |
| 6 EYE HOOK M8 x 60mm 2 PCS | 7 M8 NUT 4 PCS | 8 M8 WASHER 4 PCS | 9 CHAIN 2 PCS | |

PARTS

| | | | |
|------------------------------------|----------------------------------|----------------------------------|-----------------------------------|
| A SWING SEAT 1 PC | B BACKREST 1 PC | C LEFT ARM 1 PC | D RIGHT ARM 1 PC |
|------------------------------------|----------------------------------|----------------------------------|-----------------------------------|

PARTS

E

LEFT LEG



1 PC

F


RIGHT LEG



1 PC

G


FOLDING
CUP HOLDER



1 PC

PRODUCT ASSEMBLY - OVERALL VIEW

Look at following overall view of this swing and learn the exact position of each part to be assembled.




PRODUCT ASSEMBLY

1

Attach **Part C Left Arm** to **Part E Left Leg** with 1 set of **Hardware #2 Bolt, #4 Washer** and **#3 Nut** (see image below).

Do the same to attach **Part D Right Arm** to **Part F Right Leg** (see image below).




PRODUCT ASSEMBLY

2

Attach combined **Part F Right Leg** and **Part D Right Arm** to **Part A Swing seat** with 2 sets of **Hardware #2 Bolt, #4 Washer** and **#3 Nut** (see image below).


Do the same to attach combined **Part E Left Leg** and **Part C Right Arm** to **Part A Swing Seat**.



PRODUCT ASSEMBLY

3

Place **Part G Folding Cup Holder** to **Part B Backrest** as below and attach the cup holder to the backrest with 2 sets of **Hardware #1 Bolt, #4 Washer** and **#3 Nut** from the back side.




PRODUCT ASSEMBLY

4

Attach **Part B Backrest** with **Part G Folding Cup Holder** to **Part A Swing Seat** with 8 sets of **Hardware #2 Bolt, #4 Washer** and **#3 Nut** (see image below).

Attach **Part B Backrest** to **Part C Left Arm** and **Part D Right Arm** with 2 sets of **Hardware #2 Bolt, #4 Washer** and **#3 Nut** (see image below).




PRODUCT ASSEMBLY

5

Attach 2 sets of **Hardware #6 Eye Hook**, **#8 Washer** and **#7 Nut** to **Part B Backrest**, **Part C Left Arm** and **Part D Right Arm** as below.

Attach 2 pcs of **Hardware #5 Eye Hook** to **Part A Swing Seat** with 2 sets of **Hardware #8 Washer** and **#7 Nut** (see image below).




PRODUCT ASSEMBLY

6

Insert the long end of **Hardware #9 Chain** through the hole in the arm, turn the thread lock to open the carabiner, attach it to the eye bolt on **Part A Swing Seat** and turn back to lock.


Lock another carabiner to the eye bolt on **Part D Right Arm**.

Do the same to assemble another chain to the other side (see image below).



7

Tighten all the screws, bolts and nuts to ensure the swing is sturdy enough.



REGISTRATION & REFUND POLICY

<https://westintrends.com/apps/product-registration>



<https://westintrends.com/policies/refund-policy>



HAVING TROUBLE

- **Not sure how to assemble or missing pieces?**

Please contact our Customer Service Team for assistance at cs@westintrends.com

Have Order #, Part # or SKU ready to speed up customer service!

CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the HDPE furniture with a damp cloth. The material's resilience makes it resistant to most spills and stains, ensuring a hassle-free maintenance routine.

Regular cleaning not only preserves the aesthetic appeal of your furniture but also helps extend its lifespan.

Pressure washer can be used for seriously deep-cleaning - **DO NOT exceed 1500 PSI** - this will remove any debris and dirt.