



Safety

See safety datasheet (if applicable) and product label for safety information, handling and proper use.

Directions for Use

1. Use trigger sprayer, holding 6-8 inches from surface. Always work from bottom up. 2. Wipe dry with towel or cloth. SPECIAL INSTRUCTIONS: When used on office machinery and data processing equipment (computers), always spray on paper towel or clean cloth and then wipe area to be cleaned. Never spray directly on any surface where working office machinery or computer parts would be exposed to this product

Cleans windows, mirrors, glass display cases, CRT screens, TV screens, office equipment, Plexiglas®, plastic, painted surfaces, counters, tabletops, vinyl upholstery and any surface not damaged by water. Removes dirt, fingerprints, grease, smoke film and hair spray. Non-ammoniated formula evaporates fast to help prevent streaking or filming. Antistat formula.

Features & Benefits

Anti-stat formula won't damage electronics

Safely cleans any surface not damaged by water

Non-ammoniated formula evaporates fast for a clean streak-free surface

Item Number & Unit of Measure

Item Number	HIL0100204
Unit of Measure	32 fl oz Bottle

Specifications

Color	Blue
Appearance	Clear
Fragrance	Alcohol
Formula Type	Liquid
Dilution Ratio	RTU
PH	7.00 - 8.00
Non-Volatile Matter	< 0.5%