

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <https://tiny.cc/SunnydazeWarranty>. If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at <https://tiny.cc/SunnydazeContact>








DISPLAY STAND HMI-641

Assemble components on a soft, clean surface to avoid scratching or damaging the finish.



Inspect packaging to ensure all parts are accounted for before disposing of packing materials.



No.	PARTS	QTY.
A	 Base	1
B	 Pole	1
C	 Bolt (<i>remove from part B</i>)	1
D	 Tall Hooks with Threaded Screw	1
E	 Tall Hooks	1
F	 Medium Hooks	2 PC SET
G	 Short Hooks	2 PC SET

! HELPFUL HINT

Sunnydaze Decor advises reading this manual fully, and assembling the item soon after purchase. Check that all parts are accounted for and familiarize yourself with the assembly before beginning.

Save this manual for future reference.

ASSEMBLY

STEP 1

A: 1
B: 1
C: 1



Remove Bolt (C) from Pole (B).

Align Pole (B) with Base (A). Secure the components by tightening Bolt (C) through the underside of the base, into the pole.

STEP 2

D: 1
E: 1



Place Tall Hooks (E) over the threaded screw of Tall Hooks (D), ensuring the sections are evenly crossed.

STEP 3

B: 2 PC SET
C: 2 PC SET



Cross and stack Medium Hooks (F) and Short Hooks (G) over the threaded screw.

STEP 4



Connect the combined parts of Step 1 with the stacked decorative hooks by securing the threaded screw into the top of Pole (B).

⚠ SAFETY STATEMENTS & WARNINGS ⚠

- Recommended for indoor use only.
- Do not hang heavy objects from the hooks.
- Ensure weight is evenly distributed on the stand to prevent it from tipping over.
- This is not a toy. Always supervise children and pets.

Any modification to the product or failure to follow recommended care will void the product warranty.

⚠ WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.