





INSTRUCTIONS






TREESTAND CARRY STRAPS

HOW TO ATTACH CARRY STRAPS TO YOUR TREESTAND

Before attaching to your treestand, remove the web strap from buckle and re-thread as shown below (Fig. A & B). This will allow the webbing to lock into the buckle.



Step 1: Thread the short end of the web strap through the bottom side of the platform on the stand (Fig. D) and through the buckle strap to lock in place



SEE THE FULL TREESTAND GEAR LINEUP AT BYALLEN.COM

ALLEN Company, Inc. / 609 South 104th St., Louisville, CO 80027

⚠ **WARNING:** Cancer and reproductive harm - www.P65Warnings.ca.gov


BYALLEN



INSTRUCTIONS

TREESTAND CARRY STRAPS

Step 2: Unbuckle the webbing from the shoulder strap (Fig. J) and loop buckle through the bottom side of the platform on the treestand (Fig. K). Then thread buckle through the webbed loop on the strap (Fig. L).



Step 3: Attach the buckle back to itself to create the backpack strap (Fig. N).

Step 4: Repeat steps on the other side (Fig O).



FABRIC CONTENT

100% Polyester, Exclusive of Trim

CARE AND USE

Spot clean only with a damp cloth, air dry.
Ensure fabric is completely dry before storing



Note: ensure you are attaching the backpack straps to the bottom side of the platform on your treestand.

SEE THE FULL TREESTAND GEAR LINEUP AT BYALLEN.COM

ALLEN Company, Inc. / 609 South 104th St., Louisville, CO 80027

⚠ **WARNING:** Cancer and reproductive harm - www.P65Warnings.ca.gov

BYALLEN™