It's Under Control®

Product Contents

Contents within the box include the following items:

- One (1) T2x Remote Control
- One (1) Docking Station
- One (1) International Power Supply Kit (5V, 2A)
- One (1) Replaceable Keycap Kit (8 button keycaps and keycap replacement tool)
- One (1) Reference Guide
- One (1) Firmware Update Notification

Safety Suggestions

Read and Follow Instructions. Read all safety and operating instructions before operating the unit.

Retain Instructions. Keep the safety and operating instructions for future reference.

Heed Warnings. Adhere to all warnings on the unit and in the operating instructions.

Heat. Keep the unit away from heat sources such as radiators, heat registers, stoves, etc., including amplifiers that produce heat.

Power Sources. Use only batteries of the type described in the operating instructions, or as marked on the unit.

Water and Moisture. Do not use the unit near water—for example, near a sink, in a wet basement, near a swimming pool, near an open window, etc.

Object and Liquid Entry. Do not allow objects to fall or liquids to be spilled into the enclosure through openings.

Servicing. Do not attempt any service beyond that described in the operating instructions. Refer all other service needs to qualified service personnel. **Damage Requiring Service.** The unit should be serviced by qualified service

- Objects have fallen or liquid has been spilled into the unit.
- The unit has been exposed to rain.
- The unit does not appear to operate normally or exhibits a marked change in performance.
- The unit has been dropped or the enclosure has been damaged.

Cleaning

To clean your T2x, lightly dampen a lint-free cloth with plain water or a mild detergent and wipe the touchscreen, keypad and outer surfaces.

NOTE: Do not use harsh chemicals as damage to the unit may occur.

Limited Warranty

RTI warrants its products for a period of three (3) years (one year only for included battery packs); or for a period of time compliant with local laws when applicable from the date of purchase from RTI or an authorized RTI distributor.

This warranty may be enforced by the original purchaser and subsequent owners during the warranty period, so long as the original dated sales receipt or other proof of warranty coverage is presented when warranty service is required.

Except as specified below, this warranty covers all defects in material and workmanship in this product. The following are not covered by the warranty: Damage resulting from:

- Accident, misuse, abuse, or neglect.
- 2. Failure to follow instructions contained in this Guide.
- Repair or attempted repair by anyone other than Remote Technologies Incorporated.
- Failure to perform recommended periodic maintenance.
- Causes other than product defects, including lack of skill, competence or experience of user.
- Shipment of this product (claims must be made to the carrier).
- Being altered or which the serial number has been defaced, modified or removed.

Contacting RTI

For news about the latest updates, new product information, and new accessories, please visit our web site at: www.rticorp.com
For general information, you can contact RTI at:

Remote Technologies Incorporated 5775 12th Avenue East, Suite 180 Shakopee, MN 55379 Tel. (952) 253-3100 Fax (952) 253-3131

Service & Support

If you are encountering any problems or have a question about your RTI product, please contact RTI Technical Support for assistance (see the Contacting RTI section of this guide for contact details).

RTI provides technical support by telephone or e-mail. For the highest quality service, please have the following information ready, or provide it in your e-mail.

- Your Name
- Company Name
- · Telephone Number
- E-mail Address
- · Product model and serial number (if applicable)

If you are having a problem with hardware, please note the equipment in your system, a description of the problem, and any troubleshooting you have already tried.

If you are having a problem with software, please note what version you have installed, the operating system on your PC, a description of the problem, and any troubleshooting you have already tried. If you are calling about a software or programming question or problem, please be at your computer when you place your call. This will considerably speed up the troubleshooting process.

Please do not return products to RTI without return authorization.

Federal Communications Commission Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- This device must accept any interference received including interference that may cause undesired operation.

Industry Canada Compliance Statement

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- This device must accept any interference received including interference that may cause undesired operation.

Cet appareil est conforme avec Industrie Canada exempts de licence standard RSS (s). Son fonctionnement est soumis aux deux conditions suivantes:

- 1. Ce dispositif ne peut causer des interférences nuisibles.
- Cet appareil doit accepter toute interférence reçue y compris des interférences qui peuvent provoquer un fonctionnement indésirable.













DECLARATION OF CONFORMITY (DOC)The Declaration of Conformity for this product can be found on the RTI website at: www.rticorp.com/declaration

Copyright @ 2019 \bullet Remote Technologies Incorporated \bullet All rights reserved.



T2x Wireless Remote Control

Reference Guide



The remarkable T2x is the fifth generation of RTI's renowned T2 remote control platform. The 2.8" color display delivers vivid custom graphics, including two-way feedback with album art, while the perfect selection of soft-touch buttons provide quick access to common tasks.

Key Features

- Dual RF capability uses 433MHz and 2.4GHz (utilizing Zigbee® technology).
- Integrated 802.11b/g wireless Ethernet.
- Two-way control using 2.4GHz (Zigbee), WiFi and RTI control components.
- Flush mount, edge-to-edge touchscreen.
- Integrated grip sensors keep the remote awake while in use.
- Accelerometer provides instant-on control.

Powering On/Off the T2x

TO POWER THE T2x ON:

• Press and hold the "Backlight" button and the "OK" buttons simultaneously until the T2x powers on (Approximately 1-2 seconds).

• Place the T2x in the docking station - this will automatically power the T2x on. (Docking station does not need to be powered).

NOTE: If the unit does not power on, it may be necessary to charge the battery. See charging information below.

TO POWER THE T2x OFF:

• Press and hold the "Backlight" button, then press the "OK" button for approximately 5 seconds until the T2x powers off.

NOTE: During normal operation, powering the T2x off should not be necessary.

Charging the T2x Battery


WHEN TO CHARGE THE T2x:

The T2x uses a Lithium-ion rechargeable battery which does not exhibit a memory effect from being charged too often and may be placed into the dock when not in use.

• A low battery icon will illuminate at the top right of the T2x (above the display) when the battery capacity becomes low and a charge cycle is required.

CHARGING THE T2x:

- 1. Locate and install the appropriate wall outlet plug on to the power supply.
- 2. Insert the micro USB end of the power supply cable into the USB port located on the backside of the docking station.
- 3. Plug the power supply cable into a wall outlet.
- 4. Gently slide the T2x into the docking station clear plastic alignment sleeve until the remote is seated on to the dock connector.




Replacing the T2x Battery

The following steps for removing the battery door should be performed by an authorized service center or trained installer only.

REMOVE THE BATTERY DOOR:

- 1. Gently insert a small paper clip into the battery door latch hole until it stops (see diagram).
- 2. Tilt the paper clip toward the top of the T2x to release the battery door latch. REPLACE BATTERY:
- 1. Remove two (2) battery bracket screws
- (Phillips head) and remove bracket. 2. Slide battery out of T2x - pull on
- plastic tab connected to battery. 3. Slide new battery into T2x - metal contacts inserted first and label
- facing up. 4. Replace battery bracket and install two (2) screws - in order to align battery bracket properly, get both screws started before tightening fully.
- 5. Reinstall battery door first align the wide end of the battery door against the battery door opening, then push the latch end of the door into the T2x until it snaps in place.



Programming the T2x

THE TOUCHSCREEN DISPLAY AND HARD BUTTONS

The T2x touchscreen display and buttons are programmed using the RTI Integration Designer® programming software. (Integration Designer software available to authorized RTI dealers only).

FIRMWARE AND SOFTWARE UPDATES

Please verify that you have the most recent firmware and software installed for this and all RTI products. Authorized RTI dealers can download the latest firmware and Integration Designer from the dealer section of www.rticorp.com.

INSTALLING FIRMWARE

- 1. Turn off the T2x Press and hold the "Backlight" button and the "OK" buttons simultaneously.
- 2. Connect the T2x dock to a PC using a USB cable (USB A to Micro B).
- 3. Press and hold the "5-way Joystick" button.
- 4a. Place the T2x into the docking station.

4b. Connect the T2x to a PC directly using an RTI programming cable. (Contact your local distributor to purchase this cable. The programming cable is also included with the RTI IRPRO programming kit).

UPDATING INTEGRATION DESIGNER PROGRAMMING


RTI's Integration Designer data files can be downloaded to the T2x using the following methods:

• Connect the docking station to a PC using a USB cable (USB A to Micro B) and place the T2x into the docking station.

Or

• Connect an RTI programming cable to the T2x and a PC. (Contact your local distributor to purchase this cable. The programming cable is also included with the RTI IRPRO programming kit).

• Wirelessly via the local area Ethernet network (LAN), NOTE: Initial programming including network settings will need to take place using the docking station or the RTI programming cable.



The T2x Control Panel

The T2x has many settings that can be adjusted directly on the remote through the control panel. Please note that changes made directly in the T2x control panel will be overwritten by changes made in Integration Designer.

ACCESSING THE CONTROL PANEL

The Control Panel page can be displayed by holding down the "Backlight" button until the page is displayed (approx. 5 seconds).


ADJUSTABLE SETTINGS

- Backlight Level Time Out Tilt Switch Grip Sensor Battery
- Sound Calibrate Touchscreen Network Information

Front of T2x IR Transmission Window Light Sensor Wireless Ethernet Battery Low Indicator Connection Indicator Touchscreen Display Hard Buttons with Replaceable Keycaps: NOTE: These four button 5-Way Joystick keycaps may be replaced with the keycaps that ship with the T2i or keycaps may be ordered separately using the RTI Laser Shark custom engraving service. Visit the rticorn com dealer website for Laser Shark and button keycap replacement instructions. Programmable Keypad Buttons Backlight Button COLORS: Blue = Normal use Red = T2x charging Green = T2x charged Multi-colored = T2xconnected to a PC.

Dock Connector Port

NOTE: The T2x dock connector port is used for battery charging and downloading software/ firmware updates into the remote. To insure a reliable connection between the remote and the dock, the T2x utilizes a 10-pin connector that is compatible with a T2x Docking Station or an RTI programming cable.



THE T2x DOCKING STATION

Dock Connector: A 10-pin dock connector is used to insure a reliable connection between the remote and the dock during battery charging and software/firmware downloads.

Micro USB Port: The T2x dock has a micro USB port (located on the backside) for connection of the AC power supply cable or a standard USB A to Micro B cable for connection to a PC.