

Try this Creativity for Kids® kit!

#1819000 • Ages 5+
Fashion Headbands



- New and improved headband kit featuring new colors, trims, ribbons and must-have accessories
- Match your mood or your favorite outfit. This ultimate hair accessory set gives you everything you need to design 10 beautiful headbands
- Fluffy pom poms, rainbow ribbon, flowers, butterflies and more. Just mix and match the accessories to create your own style statement. Great for play days!

CREATIVITY counts®

Creativity Can™ develop the skills
needed to achieve lifelong success.

Creativity develops children's problem
solving and critical thinking skills – it's the
catalyst for invention, innovation and
ideas that influence the future.

www.creativitycan.com

www.CreativityforKids.com

#6222000 Magical Pom Pom Keychains
© Faber-Castell USA, Inc.
Cleveland, Ohio 44125
www.fabercastell.com
Designed in USA
Made in China
Non-toxic Safe for children
Conforms to ASTM D-4236



magical POM POM KEYCHAINS

Create 3 animal and 2 critter keychains
using simple pom pom techniques.

DECORATE

1. Place white stickers on the
animal faces.



2. For the legs, choose a color of
satin cord for each animal. For the
sloth you will need to cut the cord
in half to make two legs.
Push the satin cords through the
bottom of the animals as shown.
Even out the cords as needed.



3. Use the threader to add beaded feet
to the bottom of each cord. Even out each leg.
Move the beads up and down, until the legs
are about 3" (7.6cm) in length. Tie on the
beads and trim the excess cord.




 **WARNING:**
FUNCTIONAL SHARP EDGE

#6222000

Ages 6 to 96

MAKING THE POM POMS



- Cut a piece of yarn 10"/25.4cm long following the cutting guide printed below
- Lay the strand over the base of the tool as shown (A)
- Wrap yarn around the pom pom maker 35 times as shown (B). Don't wrap too tightly. **Note: If you wrap more than 35 times you may not have enough yarn for all pom poms.** Cut the yarn away from the ball.
- Tie the center of the yarn with the strand as shown (C).
- Flip the pom pom maker over. Bring the yarn around and tie a double knot (D).
- Slide scissors under the yarn edge and cut the ends of the loops on both sides to release the pom pom (E). **NOTE: Do not cut the "tails" of the pom poms yet. You will need these to attach two of the pom poms to the keychain.**
- Take the pom pom off, fluff, and trim (if needed) to make a circle. **Do not trim tails.**

RAINBOW POM: To create a 3 color pom pom, wrap each color yarn around the pom pom maker 10 times (15 times for 2 color pom poms). Follow steps C-E to complete.

- Repeat steps above until you've created 5 pom poms.



Do not trim tails

ASSEMBLE ANIMALS



1. Add a jump ring and keychain clip to the small hole on top of the animal. Squeeze the jump ring tight to snap it closed.

2. Gently push your pom pom half-way through the circle in your animal shape. Gently fluff the yarn. Repeat with the other two animals. (Trim the "tails" off these pom poms.)



ASSEMBLE CRITTERS

1. Take your two loose pom poms and tie the tails into the hole of the keychain. Use the threader if needed.



2. Peel and press on the glitter eyes to the center of your pom pom – press firmly to secure in place. Glue the wiggly eyes on top of the glittery glasses and lashes. Glue on the glittery feet and press the pom pom in place. Allow glue to dry completely.

3. To add ears, separate the yarn and add a small amount of glue. Push the ear into the glue and hold for a minute. Allow glue to dry completely.

When you are finished and the glue is dry, clip your magical pom poms to your backpack, purse or keys!

Save glue for touch ups and repairs.

Cleaning instructions:
Spot clean with a damp cloth as needed. Not machine washable.



10 inches / 25.4 cm

