




Purchase Date: ___/___/___ Order/Customer Reference #: _____

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <https://tiny.cc/SunnydazeWarranty> If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at <https://tiny.cc/SunnydazeContact>

CERAMIC GARDEN STOOL

Review this manual before use and save it for future reference.



GENERAL USE & CARE

Multi-functional garden stool can be used indoors and outdoors.



SAFE USE: Only use on a flat, level surface. Do not exceed the weight capacity.

MOVING: Always lift the bottom. Slowly and gently set the stool down to prevent breakage.

CLEANING: Clean with a damp cloth; do not use chemicals or abrasive materials as they may damage the glaze.

STORAGE: Avoid extreme temperatures and store indoors during periods of freezing weather.

Any modification to the product or failure to follow recommended care will void the product warranty.

⚠️ WARNING: Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

Sunnydaze Decor



SunnydazeDecor.com