




SIGONELLA CAST ALUMINUM TABLE










YUK-267

Review all assembly and care information before using this product. Save this manual for future reference.
Assemble components on a soft, clean surface to avoid damaging the finish.




 Inspect packaging to ensure all parts are accounted for before disposing of packing materials.
 Save the packing slip.

125
pounds
57 kg
Weight Capacity

No.	PARTS		QTY.
A		Leg	4
B		Panel	4
C		Tabletop	1
D		Spanner	1
E		M8x35mm Grub Screw	12
F		Flat Washer	12
G		Split Washer	12
H		Nut	12
I		Hex Key	1

⚠ WARNING ⚠
CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children and pets away during assembly.




 **SCAN THIS CODE WITH YOUR SMARTPHONE TO VIEW OUR ASSEMBLY VIDEO**

ASSEMBLY

! IMPORTANT !

Each side of Panel (B) is different.


Pay attention to installation direction to ensure panels align correctly.



STEP 1

A: 4

E: 8



- Firmly secure two Grub Screws (E) into Leg (A) using Hex Key (I).
- Repeat this step for remaining three legs.


STEP 2

B: 2

F: 4

G: 4

H: 4



- Align two Side Panels (B) as shown in the diagram at the top of this page.
- Secure the overlapping side panels to the grub screws on one of the legs using two sets of Flat Washer (F), Split Washer (G) and Nut (H).

Do not tighten hardware until Step 6 is complete.

STEP 3


A: 1

B: 1

F: 2

G: 2

H: 2




- Ensure the third Side Panel (B) is correctly aligned with a side panel from Step 1.
- Before securing the second leg, check that the top and bottom are installed in the same direction as the first leg.
- Secure the overlapping side panels to the grub screws on Leg (A) using two sets of Flat Washer (F), Split Washer (G) and Nut (H).

Do not tighten hardware until Step 6 is complete.

STEP 4

A: 1
B: 1
F: 4
G: 4
H: 4




- Ensure the last Side Panel (B) is correctly aligned, and Legs (A) are in the right direction.
- Secure the legs to the side panels using four sets of Flat Washer (F), Split Washer (G) and Nut (H).

Do not tighten hardware until Step 6 is complete.

STEP 5


C: 1
E: 4



- Place Tabletop (C) face-down on a clean, soft surface.
- Firmly secure 4x Grub Screws (E) into Leg (A) using Hex Key (I).


STEP 6

F: 4
G: 4
H: 4




- Place the assembled base over the grub screws on the tabletop.
- Secure each leg using one Flat Washer (F), Split Washer (G) and Nut (H).
- Fully tighten all nuts, from all steps, using Spanner (D).

STEP 7



Adjustable Leg-Leveling Feet



- If the table sits unevenly, simply turn the threaded feet slightly until balance is achieved.
- Please note, the adjustable leg-leveling feet are only effective on slightly uneven surfaces.

Care & Maintenance

SAFE USE: For residential use only. Only use on a flat, level surface. Never sit or stand on any part of this unit.

INSPECT: Periodically check assembly points and tighten fittings as necessary.

COVER: When not in use, cover furniture with a breathable cover to help protect it from the harmful effects of sunlight, inclement weather, as well as dust build-up, and collecting debris.

WINTER CARE & STORAGE: During winter and freezing temperatures, move the furniture to a cool, dry indoor location. Covering while in storage will help prevent dust build-up.

SCRATCHES: The powder-coating on this product is tough & durable but, even under normal use, some scratching is inevitable. Scratches can be repaired with a rust-resistant paint (not included).

WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE APPLICATION OF CHEMICAL TREATMENTS, PROTECTIVE COATINGS, TOUCH-UP PAINT, OR CLEANING PRODUCTS.

Cleaning



HAND-WASH ONLY



DO NOT USE BLEACH



DO NOT USE A PRESSURE WASHER

Mix warm water with mild detergent. Use a soft cloth to hand-wash the furniture. Rinse thoroughly with clean water, ensuring all soap residue has been removed. To prevent water spotting, dry with a soft, lint-free cloth.



SAFETY STATEMENTS & WARNINGS



- Do not exceed the weight capacity of the unit.
- Do not sit, stand, or climb on any part of this unit.
- Inspect hardware often and tighten loose hardware before use.
- Do not use harsh chemicals or abrasive materials to clean this unit.
- This product is for residential use only; institutional or commercial use will automatically void the product warranty.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with assembly or the product was damaged during shipping, please contact our customer service team through one of the methods mentioned at the top of page 1.

Please have the item number and order information ready to expedite response time.

WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.